

For Use with [TRANSPREAD](#) Density Meter .. Ali. Transpread Box, gb006 Standard Jockey..500.. Accuracy of final settings operators responsibility on use  
 ... Other rates and rate calculator can be viewed at [www.transpread.com/spreaders/trailers](http://www.transpread.com/spreaders/trailers), also available in XL format for your own computer.

Gear Box	Deep Low		RATE CHART KG. PER HA.											Low Speed Ali. Box	
Weight per litre			0.70												
	Figures in body of chart = mm of door opening														
Width	8	10	12	14	16	18	20	22	24	26	28	30	32	34	36
Rate															
20				25	28	32	36	39	43	46	50	53	57	61	64
30		27	32	37	43	48	53	59	64	69	75	80	85	91	96
40	28	36	43	50	57	64	71	78	85	93	100	107	114	121	128
50	36	45	53	62	71	80	89	98	107	116	125	134	142	151	160
60	43	53	64	75	85	96	107	117	128	139	150	160	171	182	192
70	50	62	75	87	100	112	125	137	150	162	174	187	199	212	224
80	57	71	85	100	114	128	142	157	171	185	199	214	228	242	256
90	64	80	96	112	128	144	160	176	192	208	224	240	256	272	288
100	71	89	107	125	142	160	178	196	214	231	249	267	285		
110	78	98	117	137	157	176	196	215	235	255	274	294			
120	85	107	128	150	171	192	214	235	256	278	299				
130	93	116	139	162	185	208	231	255	278						
140	100	125	150	174	199	224	249	274	299						
150	107	134	160	187	214	240	267	294							
160	114	142	171	199	228	256	285								
170	121	151	182	212	242	272									
180	128	160	192	224	256	288									
190	135	169	203	237	271										
200	142	178	214	249	285										
210	150	187	224	262	299										
220	157	196	235	274											
230	164	205	246	287											
240	171	214	256	299											
250	178	223	267												
260	185	231	278												
270	192	240	288												
280	199	249	299												
290	207	258													
300	214	267													
320	228	285													
340	242														
360	256														
380	271														
400	285														
425															
450															
475															
500															
525															
550															
575															
600															

Gear Box	Deep Low		RATE CHART KG. PER HA.											Low Speed Ali. Box	
Weight per litre			0.75												
	Figures in body of chart = mm of door opening														
Width	8	10	12	14	16	18	20	22	24	26	28	30	32	34	36
Rate															
20				23	27	30	33	37	40	43	47	50	53	56	60
30		25	30	35	40	45	50	55	60	65	70	75	80	85	90
40	27	33	40	47	53	60	66	73	80	86	93	100	106	113	120
50	33	42	50	58	66	75	83	91	100	108	116	125	133	141	150
60	40	50	60	70	80	90	100	110	120	130	140	150	160	169	179
70	47	58	70	81	93	105	116	128	140	151	163	174	186	198	209
80	53	66	80	93	106	120	133	146	160	173	186	199	213	226	239
90	60	75	90	105	120	135	150	164	179	194	209	224	239	254	269
100	66	83	100	116	133	150	166	183	199	216	233	249	266	282	299
110	73	91	110	128	146	164	183	201	219	238	256	274	292		
120	80	100	120	140	160	179	199	219	239	259	279	299			
130	86	108	130	151	173	194	216	238	259	281					
140	93	116	140	163	186	209	233	256	279						
150	100	125	150	174	199	224	249	274	299						
160	106	133	160	186	213	239	266	292							
170	113	141	169	198	226	254	282								
180	120	150	179	209	239	269	299								
190	126	158	189	221	253	284									
200	133	166	199	233	266	299									
210	140	174	209	244	279										
220	146	183	219	256	292										
230	153	191	229	268											
240	160	199	239	279											
250	166	208	249	291											
260	173	216	259												
270	179	224	269												
280	186	233	279												
290	193	241	289												
300	199	249	299												
320	213	266													
340	226	282													
360	239	299													
380	253														
400	266														
425	282														
450	299														
475															
500															
525															
550															
575															
600															

For Use with [TRANSPREAD](#) Density Meter .. Ali. Transpread Box, gb006 Standard Jockey..500.. Accuracy of final settings operators responsibility on use  
 ... Other rates and rate calculator can be viewed at [www.transpread.com/spreaders/trailers](http://www.transpread.com/spreaders/trailers), also available in XL format for your own computer.

Gear Box	Deep Low		RATE CHART KG. PER HA.													Low Speed Ali. Box
Weight per litre			0.80													
			Figures in body of chart = mm of door opening													
Width	8	10	12	14	16	18	20	22	24	26	28	30	32	34	36	
Rate																
20					25	28	31	34	37	41	44	47	50	53	56	
30		23	28	33	37	42	47	51	56	61	65	70	75	79	84	
40	25	31	37	44	50	56	62	69	75	81	87	93	100	106	112	
50	31	39	47	55	62	70	78	86	93	101	109	117	125	132	140	
60	37	47	56	65	75	84	93	103	112	122	131	140	150	159	168	
70	44	55	65	76	87	98	109	120	131	142	153	164	174	185	196	
80	50	62	75	87	100	112	125	137	150	162	174	187	199	212	224	
90	56	70	84	98	112	126	140	154	168	182	196	210	224	238	252	
100	62	78	93	109	125	140	156	171	187	203	218	234	249	265	280	
110	69	86	103	120	137	154	171	188	206	223	240	257	274	291		
120	75	93	112	131	150	168	187	206	224	243	262	280	299			
130	81	101	122	142	162	182	203	223	243	263	284					
140	87	109	131	153	174	196	218	240	262	284						
150	93	117	140	164	187	210	234	257	280							
160	100	125	150	174	199	224	249	274	299							
170	106	132	159	185	212	238	265	291								
180	112	140	168	196	224	252	280									
190	118	148	178	207	237	266	296									
200	125	156	187	218	249	280										
210	131	164	196	229	262	294										
220	137	171	206	240	274											
230	143	179	215	251	287											
240	150	187	224	262	299											
250	156	195	234	273												
260	162	203	243	284												
270	168	210	252	294												
280	174	218	262													
290	181	226	271													
300	187	234	280													
320	199	249	299													
340	212	265														
360	224	280														
380	237	296														
400	249															
425	265															
450	280															
475	296															
500																
525																
550																
575																
600																

Gear Box	Deep Low		RATE CHART KG. PER HA.													Low Speed Ali. Box
Weight per litre			0.85													
			Figures in body of chart = mm of door opening													
Width	8	10	12	14	16	18	20	22	24	26	28	30	32	34	36	
Rate																
20										23	26	29	32	35	38	
30			26	31	35	40	44	48	53	57	62	66	70	75	79	
40	23	29	35	41	47	53	59	65	70	76	82	88	94	100	106	
50	29	37	44	51	59	66	73	81	88	95	103	110	117	125	132	
60	35	44	53	62	70	79	88	97	106	114	123	132	141	150	158	
70	41	51	62	72	82	92	103	113	123	133	144	154	164	174	185	
80	47	59	70	82	94	106	117	129	141	152	164	176	188	199	211	
90	53	66	79	92	106	119	132	145	158	172	185	198	211	224	238	
100	59	73	88	103	117	132	147	161	176	191	205	220	235	249	264	
110	65	81	97	113	129	145	161	177	194	210	226	242	258	274	290	
120	70	88	106	123	141	158	176	194	211	229	246	264	281	299		
130	76	95	114	133	152	172	191	210	229	248	267	286				
140	82	103	123	144	164	185	205	226	246	267	287					
150	88	110	132	154	176	198	220	242	264	286						
160	94	117	141	164	188	211	235	258	281							
170	100	125	150	174	199	224	249	274	299							
180	106	132	158	185	211	238	264	290								
190	111	139	167	195	223	251	279									
200	117	147	176	205	235	264	293									
210	123	154	185	216	246	277										
220	129	161	194	226	258	290										
230	135	169	202	236	270											
240	141	176	211	246	281											
250	147	183	220	257	293											
260	152	191	229	267												
270	158	198	238	277												
280	164	205	246	287												
290	170	213	255	298												
300	176	220	264													
320	188	235	281													
340	199	249	299													
360	211	264														
380	223	279														
400	235	293														
425	249															
450	264															
475	279															
500	293															
525																
550																
575																
600																

For Use with [TRANSPREAD](#) Density Meter .. Ali. Transpread Box, gb006 Standard Jockey..500.. Accuracy of final settings operators responsibility on use  
 ... Other rates and rate calculator can be viewed at [www.transpread.com/spreaders/trailers](http://www.transpread.com/spreaders/trailers), also available in XL format for your own computer.

Gear Box	Deep Low		RATE CHART KG. PER HA.												Low Speed Ali. Box	
Weight per litre			0.90													
	Figures in body of chart = mm of door opening															
Width	8	10	12	14	16	18	20	22	24	26	28	30	32	34	36	
Rate																
20						25	28	30	33	36	39	42	44	47	50	
30			25	29	33	37	42	46	50	54	58	62	66	71	75	
40		28	33	39	44	50	55	61	66	72	78	83	89	94	100	
50	28	35	42	48	55	62	69	76	83	90	97	104	111	118	125	
60	33	42	50	58	66	75	83	91	100	108	116	125	133	141	150	
70	39	48	58	68	78	87	97	107	116	126	136	145	155	165	174	
80	44	55	66	78	89	100	111	122	133	144	155	166	177	188	199	
90	50	62	75	87	100	112	125	137	150	162	174	187	199	212	224	
100	55	69	83	97	111	125	138	152	166	180	194	208	222	235	249	
110	61	76	91	107	122	137	152	168	183	198	213	228	244	259	274	
120	66	83	100	116	133	150	166	183	199	216	233	249	266	282	299	
130	72	90	108	126	144	162	180	198	216	234	252	270	288			
140	78	97	116	136	155	174	194	213	233	252	271	291				
150	83	104	125	145	166	187	208	228	249	270	291					
160	89	111	133	155	177	199	222	244	266	288						
170	94	118	141	165	188	212	235	259	282							
180	100	125	150	174	199	224	249	274	299							
190	105	132	158	184	210	237	263	289								
200	111	138	166	194	222	249	277									
210	116	145	174	204	233	262	291									
220	122	152	183	213	244	274										
230	127	159	191	223	255	287										
240	133	166	199	233	266	299										
250	138	173	208	242	277											
260	144	180	216	252	288											
270	150	187	224	262	299											
280	155	194	233	271												
290	161	201	241	281												
300	166	208	249	291												
320	177	222	266													
340	188	235	282													
360	199	249	299													
380	210	263														
400	222	277														
425	235	294														
450	249															
475	263															
500	277															
525	291															
550																
575																
600																

Gear Box	Deep Low		RATE CHART KG. PER HA.												Low Speed Ali. Box	
Weight per litre			0.95													
	Figures in body of chart = mm of door opening															
Width	8	10	12	14	16	18	20	22	24	26	28	30	32	34	36	
Rate																
20																
30			24	28	31	35	39	43	47	51	55	59	63	67	71	
40		26	31	37	42	47	52	58	63	68	73	79	84	89	94	
50	26	33	39	46	52	59	66	72	79	85	92	98	105	111	118	
60	31	39	47	55	63	71	79	87	94	102	110	118	126	134	142	
70	37	46	55	64	73	83	92	101	110	119	129	138	147	156	165	
80	42	52	63	73	84	94	105	115	126	136	147	157	168	178	189	
90	47	59	71	83	94	106	118	130	142	153	165	177	189	201	213	
100	52	66	79	92	105	118	131	144	157	171	184	197	210	223	236	
110	58	72	87	101	115	130	144	159	173	188	202	216	231	245	260	
120	63	79	94	110	126	142	157	173	189	205	220	236	252	268	283	
130	68	85	102	119	136	153	171	188	205	222	239	256	273	290		
140	73	92	110	129	147	165	184	202	220	239	257	275	294			
150	79	98	118	138	157	177	197	216	236	256	275	295				
160	84	105	126	147	168	189	210	231	252	273	294					
170	89	111	134	156	178	201	223	245	268	290						
180	94	118	142	165	189	213	236	260	283							
190	100	125	150	174	199	224	249	274	299							
200	105	131	157	184	210	236	262	289								
210	110	138	165	193	220	248	275									
220	115	144	173	202	231	260	289									
230	121	151	181	211	241	272										
240	126	157	189	220	252	283										
250	131	164	197	230	262	295										
260	136	171	205	239	273											
270	142	177	213	248	283											
280	147	184	220	257	294											
290	152	190	228	266												
300	157	197	236	275												
320	168	210	252	294												
340	178	223	268													
360	189	236	283													
380	199	249	299													
400	210	262														
425	223	279														
450	236	295														
475	249															
500	262															
525	275															
550	289															
575																
600																





For Use with [TRANSPREAD](#) Density Meter .. Ali. Transpread Box, gb006 Standard Jockey..500.. Accuracy of final settings operators responsibility on use  
 ... Other rates and rate calculator can be viewed at [www.transpread.com/spreaders/trailers](http://www.transpread.com/spreaders/trailers), also available in XL format for your own computer.

Gear Box	Deep Low		RATE CHART KG. PER HA.													Low Speed Ali. Box	
Weight per litre			1.30														
Width	8	10	12	14	16	18	20	22	24	26	28	30	32	34	36		
Rate	Figures in body of chart = mm of door opening																
20									23	25	27	29	31	33	35		
30					23	26	29	32	35	37	40	43	46	49	52		
40			23	27	31	35	38	42	46	50	54	58	61	65	69		
50		24	29	34	38	43	48	53	58	62	67	72	77	81	86		
60	23	29	35	40	46	52	58	63	69	75	81	86	92	98	104		
70	27	34	40	47	54	60	67	74	81	87	94	101	107	114	121		
80	31	38	46	54	61	69	77	84	92	100	107	115	123	130	138		
90	35	43	52	60	69	78	86	95	104	112	121	129	138	147	155		
100	38	48	58	67	77	86	96	105	115	125	134	144	153	163	173		
110	42	53	63	74	84	95	105	116	127	137	148	158	169	179	190		
120	46	58	69	81	92	104	115	127	138	150	161	173	184	196	207		
130	50	62	75	87	100	112	125	137	150	162	174	187	199	212	224		
140	54	67	81	94	107	121	134	148	161	174	188	201	215	228	242		
150	58	72	86	101	115	129	144	158	173	187	201	216	230	244	259		
160	61	77	92	107	123	138	153	169	184	199	215	230	245	261	276		
170	65	81	98	114	130	147	163	179	196	212	228	244	261	277	293		
180	69	86	104	121	138	155	173	190	207	224	242	259	276	293			
190	73	91	109	127	146	164	182	200	219	237	255	273	291				
200	77	96	115	134	153	173	192	211	230	249	268	288					
210	81	101	121	141	161	181	201	221	242	262	282						
220	84	105	127	148	169	190	211	232	253	274	295						
230	88	110	132	154	176	198	220	243	265	287							
240	92	115	138	161	184	207	230	253	276	299							
250	96	120	144	168	192	216	240	264	288								
260	100	125	150	174	199	224	249	274	299								
270	104	129	155	181	207	233	259	285									
280	107	134	161	188	215	242	268	295									
290	111	139	167	195	222	250	278										
300	115	144	173	201	230	259	288										
320	123	153	184	215	245	276											
340	130	163	196	228	261	293											
360	138	173	207	242	276												
380	146	182	219	255	291												
400	153	192	230	268													
425	163	204	244	285													
450	173	216	259														
475	182	228	273														
500	192	240	288														
525	201	252															
550	211	264															
575	220	276															
600	230	288															

Gear Box	Deep Low		RATE CHART KG. PER HA.													Low Speed Ali. Box	
Weight per litre			1.40														
Width	8	10	12	14	16	18	20	22	24	26	28	30	32	34	36		
Rate	Figures in body of chart = mm of door opening																
20																	
30																23	25
40											24	27	29	32	35	37	40
50											27	31	36	40	45	49	53
60											32	37	43	48	53	59	64
70											37	44	50	56	62	69	75
80											43	50	57	64	71	78	85
90											48	56	64	72	80	88	96
100											53	62	71	80	89	98	107
110											59	69	78	88	98	108	117
120											64	75	85	96	107	117	128
130											69	81	93	104	116	127	139
140											75	87	100	112	125	137	150
150											80	93	107	120	134	147	160
160											85	100	114	128	142	157	171
170											91	106	121	136	151	166	182
180											96	112	128	144	160	176	192
190											101	118	135	152	169	186	203
200											107	125	142	160	178	196	214
210											112	131	150	168	187	206	224
220											117	137	157	176	196	215	235
230											123	143	164	184	205	225	246
240											128	150	171	192	214	235	256
250											134	156	178	200	223	245	267
260											139	162	185	208	231	255	278
270											144	168	192	216	240	264	288
280											150	174	199	224	249	274	299
290											155	181	207	232	258	284	
300											160	187	214	240	267	294	
320											171	199	228	256	285		
340											182	212	242	272			
360											192	224	256	288			
380											203	237	271				
400											214	249	285				
425											227	265					
450											240	280					
475											254	296					
500											267						
525											280						
550											294						
575											256						
600											267						

For Use with [TRANSPREAD](#) Density Meter .. Ali. Transpread Box, gb006 Standard Jockey..500.. Accuracy of final settings operators responsibility on use  
 ... Other rates and rate calculator can be viewed at [www.transpread.com/spreaders/trailers](http://www.transpread.com/spreaders/trailers), also available in XL format for your own computer.

Gear Box	Deep Low		RATE CHART KG. PER HA.												Low Speed Ali. Box
Weight per litre			1.50												
	Figures in body of chart = mm of door opening														
Width	8	10	12	14	16	18	20	22	24	26	28	30	32	34	36
Rate	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
20											23	25	27	28	30
30							25	27	30	32	35	37	40	42	45
40				23	27	30	33	37	40	43	47	50	53	56	60
50			25	29	33	37	42	46	50	54	58	62	66	71	75
60		25	30	35	40	45	50	55	60	65	70	75	80	85	90
70	23	29	35	41	47	52	58	64	70	76	81	87	93	99	105
80	27	33	40	47	53	60	66	73	80	86	93	100	106	113	120
90	30	37	45	52	60	67	75	82	90	97	105	112	120	127	135
100	33	42	50	58	66	75	83	91	100	108	116	125	133	141	150
110	37	46	55	64	73	82	91	101	110	119	128	137	146	155	164
120	40	50	60	70	80	90	100	110	120	130	140	150	160	169	179
130	43	54	65	76	86	97	108	119	130	140	151	162	173	184	194
140	47	58	70	81	93	105	116	128	140	151	163	174	186	198	209
150	50	62	75	87	100	112	125	137	150	162	174	187	199	212	224
160	53	66	80	93	106	120	133	146	160	173	186	199	213	226	239
170	56	71	85	99	113	127	141	155	169	184	198	212	226	240	254
180	60	75	90	105	120	135	150	164	179	194	209	224	239	254	269
190	63	79	95	110	126	142	158	174	189	205	221	237	253	268	284
200	66	83	100	116	133	150	166	183	199	216	233	249	266	282	299
210	70	87	105	122	140	157	174	192	209	227	244	262	279	297	
220	73	91	110	128	146	164	183	201	219	238	256	274	292		
230	76	96	115	134	153	172	191	210	229	248	268	287			
240	80	100	120	140	160	179	199	219	239	259	279	299			
250	83	104	125	145	166	187	208	228	249	270	291				
260	86	108	130	151	173	194	216	238	259	281					
270	90	112	135	157	179	202	224	247	269	292					
280	93	116	140	163	186	209	233	256	279						
290	96	120	145	169	193	217	241	265	289						
300	100	125	150	174	199	224	249	274	299						
320	106	133	160	186	213	239	266	292							
340	113	141	169	198	226	254	282								
360	120	150	179	209	239	269	299								
380	126	158	189	221	253	284									
400	133	166	199	233	266	299									
425	141	177	212	247	282										
450	150	187	224	262	299										
475	158	197	237	276											
500	166	208	249	291											
525	174	218	262												
550	183	228	274												
575	191	239	287												
600	199	249	299												

Gear Box	Deep Low		RATE CHART KG. PER HA.												Low Speed Ali. Box
Weight per litre			1.60												
	Figures in body of chart = mm of door opening														
Width	8	10	12	14	16	18	20	22	24	26	28	30	32	34	36
Rate	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
20															
30															
40															
50															
60															
70															
80															
90															
100															
110															
120															
130															
140															
150															
160															
170															
180															
190															
200															
210															
220															
230															
240															
250															
260															
270															
280															
290															
300															
320															
340															
360															
380															
400															
425															
450															
475															
500															
525															
550															
575															
600															





For Use with **TRANSPREAD** Density Meter , Ali. Transpread Box, gb006 Standard Jockey..500. Accuracy of final settings operators responsibility on use  
 Other rates and rate calculator can be viewed at [www.transpread.com/spreaders/trailers](http://www.transpread.com/spreaders/trailers), also available in XL format for your own computer.

Gear Box...Med. Gear Weight per litre	RATE CHART KG. PER HA.														Low Speed Ali. Box				
	0.80														Figures in body of chart = mm of door openir				
Width	8	10	12	14	16	18	20	22	24	26	28	30	32	34	36				
Rate																			
100	27	34	41	47	54	61	68	74	81	88	95	101	108	115	122				
110	30	37	45	52	59	67	74	82	89	97	104	111	119	126	134				
120	32	41	49	57	65	73	81	89	97	105	113	122	130	138	146				
130	35	44	53	61	70	79	88	97	105	114	123	132	140	149	158				
140	38	47	57	66	76	85	95	104	113	123	132	142	151	161	170				
150	41	51	61	71	81	91	101	111	122	132	142	152	162	172	182				
160	43	54	65	76	86	97	108	119	130	140	151	162	173	184	194				
170	46	57	69	80	92	103	115	126	138	149	161	172	184	195	207				
180	49	61	73	85	97	109	122	134	146	158	170	182	194	207	219				
190	51	64	77	90	103	115	128	141	154	167	180	192	205	218	231				
200	54	68	81	95	108	122	135	149	162	176	189	203	216	230	243				
210	57	71	85	99	113	128	142	156	170	184	198	213	227	241	255				
220	59	74	89	104	119	134	149	163	178	193	208	223	238	252	267				
230	62	78	93	109	124	140	155	171	186	202	217	233	248	264	279				
240	65	81	97	113	130	146	162	178	194	211	227	243	259	275	292				
250	68	84	101	118	135	152	169	186	203	219	236	253	270	287					
260	70	88	105	123	140	158	176	193	211	228	246	263	281	298					
270	73	91	109	128	146	164	182	200	219	237	255	273	292						
280	76	95	113	132	151	170	189	208	227	246	265	284							
290	78	98	117	137	157	176	196	215	235	254	274	294							
300	81	101	122	142	162	182	203	223	243	263	284								
320	86	108	130	151	173	194	216	238	259	281									
340	92	115	138	161	184	207	230	252	275	298									
360	97	122	146	170	194	219	243	267	292										
380	103	128	154	180	205	231	257	282											
400	108	135	162	189	216	243	270	297											
425	115	143	172	201	230	258	287												
450	122	152	182	213	243	273													
475	128	160	192	224	257	289													
500	135	169	203	236	270														
525	142	177	213	248	284														
550	149	186	223	260	297														
575	155	194	233	272															
600	162	203	243	284															
650	176	219	263																
700	189	236	284																
750	203	253																	
800	216	270																	
850	230	287																	
900	243																		
950	257																		
1000	270																		

Gear Box...Med. Gear Weight per litre	RATE CHART KG. PER HA.														Low Speed Ali. Box				
	0.85														Figures in body of chart = mm of door openir				
Width	8	10	12	14	16	18	20	22	24	26	28	30	32	34	36				
Rate																			
100	25	32	38	44	51	57	64	70	76	83	89	95	102	108	114				
110	28	35	42	49	56	63	70	77	84	91	98	105	112	119	126				
120	30	38	46	53	61	69	76	84	91	99	107	114	122	130	137				
130	33	41	50	58	66	74	83	91	99	107	116	124	132	140	149				
140	36	44	53	62	71	80	89	98	107	116	125	133	142	151	160				
150	38	48	57	67	76	86	95	105	114	124	133	143	152	162	172				
160	41	51	61	71	81	91	102	112	122	132	142	152	163	173	183				
170	43	54	65	76	86	97	108	119	130	140	151	162	173	184	194				
180	46	57	69	80	91	103	114	126	137	149	160	172	183	194	206				
190	48	60	72	84	97	109	121	133	145	157	169	181	193	205	217				
200	51	64	76	89	102	114	127	140	152	165	178	191	203	216	229				
210	53	67	80	93	107	120	133	147	160	173	187	200	213	227	240				
220	56	70	84	98	112	126	140	154	168	182	196	210	224	238	252				
230	58	73	88	102	117	132	146	161	175	190	205	219	234	248	263				
240	61	76	91	107	122	137	152	168	183	198	213	229	244	259	274				
250	64	79	95	111	127	143	159	175	191	206	222	238	254	270	286				
260	66	83	99	116	132	149	165	182	198	215	231	248	264	281	297				
270	69	86	103	120	137	154	172	189	206	223	240	257	274	292					
280	71	89	107	125	142	160	178	196	213	231	249	267	285						
290	74	92	111	129	147	166	184	203	221	240	258	276	295						
300	76	95	114	133	152	172	191	210	229	248	267	286							
320	81	102	122	142	163	183	203	224	244	264	285								
340	86	108	130	151	173	194	216	238	259	281									
360	91	114	137	160	183	206	229	252	274	297									
380	97	121	145	169	193	217	241	266	290										
400	102	127	152	178	203	229	254	280											
425	108	135	162	189	216	243	270	297											
450	114	143	172	200	229	257	286												
475	121	151	181	211	241	272													
500	127	159	191	222	254	286													
525	133	167	200	233	267														
550	140	175	210	245	280														
575	146	183	219	256	292														
600	152	191	229	267															
650	165	206	248	289															
700	178	222	267																
750	191	238	286																
800	203	254																	
850	216	270																	
900	229	286																	
950	241																		
1000	254																		











For Use with [TRANSPREAD](#) Density Meter .. Ali. Transpread Box, gb006, Standard Jockey..500. Accuracy of final settings operators responsibility on use  
 Other rates and rate calculator can be viewed at [www.transpread.com/spreaders/trailers](http://www.transpread.com/spreaders/trailers), also available in XL format for your own computer.

Gear Box...High. Gear		RATE CHART KG. PER HA.													Low Speed Ali. Box		
Weight per litre		0.75													Figures in body of chart = mm of door opening		
Width.	8	10	12	14	16	18	20	22	24	26	28	30	32	34	36		
Rate	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
600	48	60	73	85	97	109	121	133	145	157	169	181	194	206	218		
625	50	63	76	88	101	113	126	139	151	164	176	189	202	214	227		
650	52	66	79	92	105	118	131	144	157	170	183	197	210	223	236		
675	54	68	82	95	109	122	136	150	163	177	191	204	218	231	245		
700	56	71	85	99	113	127	141	155	169	183	198	212	226	240	254		
750	60	76	91	106	121	136	151	166	181	197	212	227	242	257	272		
800	65	81	97	113	129	145	161	177	194	210	226	242	258	274	290		
850	69	86	103	120	137	154	171	188	206	223	240	257	274	291	308		
900	73	91	109	127	145	163	181	200	218	236	254	272	290	308			
950	77	96	115	134	153	172	192	211	230	249	268	287	306				
1000	81	101	121	141	161	181	202	222	242	262	282	302					
1050	85	106	127	148	169	191	212	233	254	275	296	318					
1100	89	111	133	155	177	200	222	244	266	288	310						
1150	93	116	139	162	185	209	232	255	278	301							
1200	97	121	145	169	194	218	242	266	290	314							
1250	101	126	151	176	202	227	252	277	302								
1300	105	131	157	183	210	236	262	288	314								
1350	109	136	163	191	218	245	272	299									
1400	113	141	169	198	226	254	282	310									
1450	117	146	175	205	234	263	292										
1500	121	151	181	212	242	272	302										
1550	125	156	187	219	250	281	312										
1600	129	161	194	226	258	290											
1650	133	166	200	233	266	299											
1700	137	171	206	240	274	308											
1800	145	181	218	254	290												
1900	153	192	230	268	306												
2000	161	202	242	282													
2500	202	252	302														
3000	242	302															
3500	282																
4000																	
5000																	
6000																	
7000																	
8000																	
9000																	
10000																	

  

Gear Box...High. Gear		RATE CHART KG. PER HA.													Low Speed Ali. Box		
Weight per litre		0.80													Figures in body of chart = mm of door opening		
Width.	8	10	12	14	16	18	20	22	24	26	28	30	32	34	36		
Rate	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
600	45	57	68	79	91	102	113	125	136	147	159	170	181	193	204		
625	47	59	71	83	95	106	118	130	142	154	165	177	189	201	213		
650	49	61	74	86	98	111	123	135	147	160	172	184	197	209	221		
675	51	64	77	89	102	115	128	140	153	166	179	191	204	217	230		
700	53	66	79	93	106	119	132	146	159	172	185	198	212	225	238		
750	57	71	85	99	113	128	142	156	170	184	198	213	227	241	255		
800	60	76	91	106	121	136	151	166	181	197	212	227	242	257	272		
850	64	80	96	112	129	145	161	177	193	209	225	241	257	273	289		
900	68	85	102	119	136	153	170	187	204	221	238	255	272	289	306		
950	72	90	108	126	144	162	180	198	215	233	251	269	287	305			
1000	76	95	113	132	151	170	189	208	227	246	265	284	302				
1050	79	99	119	139	159	179	198	218	238	258	278	298	318				
1100	83	104	125	146	166	187	208	229	249	270	291	312					
1150	87	109	130	152	174	196	217	239	261	283	304						
1200	91	113	136	159	181	204	227	249	272	295	318						
1250	95	118	142	165	189	213	236	260	284	307							
1300	98	123	147	172	197	221	246	270	295	319							
1350	102	128	153	179	204	230	255	281	306								
1400	106	132	159	185	212	238	265	291	318								
1450	110	137	164	192	219	247	274	301									
1500	113	142	170	198	227	255	284	312									
1550	117	146	176	205	234	264	293										
1600	121	151	181	212	242	272	302										
1650	125	156	187	218	249	281	312										
1700	129	161	193	225	257	289											
1800	136	170	204	238	272	306											
1900	144	180	215	251	287												
2000	151	189	227	265	302												
2500	189	236	284														
3000	227	284															
3500	265																
4000	302																
5000																	
6000																	
7000																	
8000																	
9000																	
10000																	

For Use with [TRANSPREAD](#) Density Meter .. Ali. Transpread Box, gb006, Standard Jockey..500. Accuracy of final settings operators responsibility on use  
 Other rates and rate calculator can be viewed at [www.transpread.com/spreaders/trailers](http://www.transpread.com/spreaders/trailers), also available in XL format for your own computer.

Gear Box...High. Gear		RATE CHART KG. PER HA.													Low Speed Ali. Box		
Weight per litre		0.85													Low Speed Ali. Box		
		Figures in body of chart = mm of door opening															
Width.	8	10	12	14	16	18	20	22	24	26	28	30	32	34	36		
Rate	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
600	43	53	64	75	85	96	107	117	128	139	149	160	171	181	192		
625	44	56	67	78	89	100	111	122	133	145	156	167	178	189	200		
650	46	58	69	81	92	104	116	127	139	150	162	173	185	197	208		
675	48	60	72	84	96	108	120	132	144	156	168	180	192	204	216		
700	50	62	75	87	100	112	125	137	149	162	174	187	199	212	224		
750	53	67	80	93	107	120	133	147	160	173	187	200	213	227	240		
800	57	71	85	100	114	128	142	157	171	185	199	213	228	242	256		
850	60	76	91	106	121	136	151	166	181	197	212	227	242	257	272		
900	64	80	96	112	128	144	160	176	192	208	224	240	256	272	288		
950	68	84	101	118	135	152	169	186	203	220	237	253	270	287	304		
1000	71	89	107	125	142	160	178	196	213	231	249	267	285	302			
1050	75	93	112	131	149	168	187	205	224	243	261	280	299	318			
1100	78	98	117	137	157	176	196	215	235	254	274	294	313				
1150	82	102	123	143	164	184	205	225	245	266	286	307					
1200	85	107	128	149	171	192	213	235	256	277	299						
1250	89	111	133	156	178	200	222	245	267	289	311						
1300	92	116	139	162	185	208	231	254	277	301							
1350	96	120	144	168	192	216	240	264	288	312							
1400	100	125	149	174	199	224	249	274	299								
1450	103	129	155	181	206	232	258	284	310								
1500	107	133	160	187	213	240	267	294									
1550	110	138	165	193	221	248	276	303									
1600	114	142	171	199	228	256	285	313									
1650	117	147	176	205	235	264	294										
1700	121	151	181	212	242	272	302										
1800	128	160	192	224	256	288											
1900	135	169	203	237	270	304											
2000	142	178	213	249	285												
2500	178	222	267	311													
3000	213	267															
3500	249	311															
4000	285																
5000																	
6000																	
7000																	
8000																	
9000																	
10000																	

  

Gear Box...High. Gear		RATE CHART KG. PER HA.													Low Speed Ali. Box		
Weight per litre		0.90													Low Speed Ali. Box		
		Figures in body of chart = mm of door opening															
Width.	8	10	12	14	16	18	20	22	24	26	28	30	32	34	36		
Rate	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
600	40	50	60	71	81	91	101	111	121	131	141	151	161	171	181		
625	42	53	63	74	84	95	105	116	126	137	147	158	168	179	189		
650	44	55	66	76	87	98	109	120	131	142	153	164	175	186	197		
675	45	57	68	79	91	102	113	125	136	147	159	170	181	193	204		
700	47	59	71	82	94	106	118	129	141	153	165	176	188	200	212		
750	50	63	76	88	101	113	126	139	151	164	176	189	202	214	227		
800	54	67	81	94	108	121	134	148	161	175	188	202	215	228	242		
850	57	71	86	100	114	129	143	157	171	186	200	214	228	243	257		
900	60	76	91	106	121	136	151	166	181	197	212	227	242	257	272		
950	64	80	96	112	128	144	160	176	192	207	223	239	255	271	287		
1000	67	84	101	118	134	151	168	185	202	218	235	252	269	286	302		
1050	71	88	106	123	141	159	176	194	212	229	247	265	282	300	318		
1100	74	92	111	129	148	166	185	203	222	240	259	277	296	314			
1150	77	97	116	135	155	174	193	213	232	251	270	290	309				
1200	81	101	121	141	161	181	202	222	242	262	282	302					
1250	84	105	126	147	168	189	210	231	252	273	294	315					
1300	87	109	131	153	175	197	218	240	262	284	306						
1350	91	113	136	159	181	204	227	249	272	295	318						
1400	94	118	141	165	188	212	235	259	282	306							
1450	97	122	146	171	195	219	244	268	292	317							
1500	101	126	151	176	202	227	252	277	302								
1550	104	130	156	182	208	234	260	286	312								
1600	108	134	161	188	215	242	269	296									
1650	111	139	166	194	222	249	277	305									
1700	114	143	171	200	228	257	286	314									
1800	121	151	181	212	242	272	302										
1900	128	160	192	223	255	287	319										
2000	134	168	202	235	269	302											
2500	168	210	252	294													
3000	202	252	302														
3500	235	294															
4000	269																
5000																	
6000																	
7000																	
8000																	
9000																	
10000																	









For Use with [TRANSPREAD](#) Density Meter .. Ali. Transpread Box, gb006, Standard Jockey..500. Accuracy of final settings operators responsibility on use  
 Other rates and rate calculator can be viewed at [www.transpread.com/spreaders/trailers](http://www.transpread.com/spreaders/trailers), also available in XL format for your own computer.

Gear Box...High. Gear		RATE CHART KG. PER HA.													Low Speed Ali. Box					
Weight per litre		1.50													Figures in body of chart = mm of door opening					
Width.	8	10	12	14	16	18	20	22	24	26	28	30	32	34	36					
Rate																				
600	24	30	36	42	48	54	60	67	73	79	85	91	97	103	109					
625	25	32	38	44	50	57	63	69	76	82	88	95	101	107	113					
650	26	33	39	46	52	59	66	72	79	85	92	98	105	111	118					
675	27	34	41	48	54	61	68	75	82	88	95	102	109	116	122					
700	28	35	42	49	56	64	71	78	85	92	99	106	113	120	127					
750	30	38	45	53	60	68	76	83	91	98	106	113	121	129	136					
800	32	40	48	56	65	73	81	89	97	105	113	121	129	137	145					
850	34	43	51	60	69	77	86	94	103	111	120	129	137	146	154					
900	36	45	54	64	73	82	91	100	109	118	127	136	145	154	163					
950	38	48	57	67	77	86	96	105	115	124	134	144	153	163	172					
1000	40	50	60	71	81	91	101	111	121	131	141	151	161	171	181					
1050	42	53	64	74	85	95	106	116	127	138	148	159	169	180	191					
1100	44	55	67	78	89	100	111	122	133	144	155	166	177	188	200					
1150	46	58	70	81	93	104	116	128	139	151	162	174	185	197	209					
1200	48	60	73	85	97	109	121	133	145	157	169	181	194	206	218					
1250	50	63	76	88	101	113	126	139	151	164	176	189	202	214	227					
1300	52	66	79	92	105	118	131	144	157	170	183	197	210	223	236					
1350	54	68	82	95	109	122	136	150	163	177	191	204	218	231	245					
1400	56	71	85	99	113	127	141	155	169	183	198	212	226	240	254					
1450	58	73	88	102	117	132	146	161	175	190	205	219	234	248	263					
1500	60	76	91	106	121	136	151	166	181	197	212	227	242	257	272					
1550	62	78	94	109	125	141	156	172	187	203	219	234	250	266	281					
1600	65	81	97	113	129	145	161	177	194	210	226	242	258	274	290					
1650	67	83	100	116	133	150	166	183	200	216	233	249	266	283	299					
1700	69	86	103	120	137	154	171	188	206	223	240	257	274	291	308					
1800	73	91	109	127	145	163	181	200	218	236	254	272	290	308						
1900	77	96	115	134	153	172	192	211	230	249	268	287	306							
2000	81	101	121	141	161	181	202	222	242	262	282	302								
2500	101	126	151	176	202	227	252	277	302											
3000	121	151	181	212	242	272	302													
3500	141	176	212	247	282	318														
4000	161	202	242	282																
5000	202	252	302																	
6000	242	302																		
7000	282																			
8000																				
9000																				
10000																				

  

Gear Box...High. Gear		RATE CHART KG. PER HA.													Low Speed Ali. Box					
Weight per litre		1.60													Figures in body of chart = mm of door opening					
Width.	8	10	12	14	16	18	20	22	24	26	28	30	32	34	36					
Rate																				
600		28	34	40	45	51	57	62	68	74	79	85	91	96	102					
625	24	30	35	41	47	53	59	65	71	77	83	89	95	100	106					
650	25	31	37	43	49	55	61	68	74	80	86	92	98	104	111					
675	26	32	38	45	51	57	64	70	77	83	89	96	102	108	115					
700	26	33	40	46	53	60	66	73	79	86	93	99	106	112	119					
750	28	35	43	50	57	64	71	78	85	92	99	106	113	120	128					
800	30	38	45	53	60	68	76	83	91	98	106	113	121	129	136					
850	32	40	48	56	64	72	80	88	96	104	112	120	129	137	145					
900	34	43	51	60	68	77	85	94	102	111	119	128	136	145	153					
950	36	45	54	63	72	81	90	99	108	117	126	135	144	153	162					
1000	38	47	57	66	76	85	95	104	113	123	132	142	151	161	170					
1050	40	50	60	69	79	89	99	109	119	129	139	149	159	169	179					
1100	42	52	62	73	83	94	104	114	125	135	146	156	166	177	187					
1150	43	54	65	76	87	98	109	120	130	141	152	163	174	185	196					
1200	45	57	68	79	91	102	113	125	136	147	159	170	181	193	204					
1250	47	59	71	83	95	106	118	130	142	154	165	177	189	201	213					
1300	49	61	74	86	98	111	123	135	147	160	172	184	197	209	221					
1350	51	64	77	89	102	115	128	140	153	166	179	191	204	217	230					
1400	53	66	79	93	106	119	132	146	159	172	185	198	212	225	238					
1450	55	69	82	96	110	123	137	151	164	178	192	206	219	233	247					
1500	57	71	85	99	113	128	142	156	170	184	198	213	227	241	255					
1550	59	73	88	103	117	132	146	161	176	190	205	220	234	249	264					
1600	60	76	91	106	121	136	151	166	181	197	212	227	242	257	272					
1650	62	78	94	109	125	140	156	172	187	203	218	234	249	265	281					
1700	64	80	96	112	129	145	161	177	193	209	225	241	257	273	289					
1800	68	85	102	119	136	153	170	187	204	221	238	255	272	289	306					
1900	72	90	108	126	144	162	180	198	215	233	251	269	287	305						
2000	76	95	113	132	151	170	189	208	227	246	265	284	302							
2500	95	118	142	165	189	213	236	260	284	307										
3000	113	142	170	198	227	255	284	312												
3500	132	165	198	232	265	298														
4000	151	189	227	265	302															
5000	189	236	284																	
6000	227	284																		
7000	265																			
8000	302																			
9000																				
10000																				