

For Use with [TRANSPREAD](#) Density Meter ..gb007, 730 Standard Jockey. Accuracy of final settings operators responsibility based on use
 ... Other rates and rate calculator can be viewed at www.transpread.com/spreaders/trailers, also available in XL format for your own computer.

Gear Box...Low. Gear		RATE CHART LB. PER ACRE gb007, 730													
Density Lb. Per Cu Ft.		45 Figures in body of chart = mm of door opening													
Width.	25	30	35	40	45	50	55	60	65	70	80	90	100	120	130
Rate															
20							25	28	30	32	37	41	46	55	55
30							41	45	48	55	62	69	69	83	83
40		28	32	37	41	46	51	55	60	65	74	83	92	92	111
50	29	35	40	46	52	58	63	69	75	81	92	104	115	115	138
60	35	41	48	55	62	69	76	83	90	97	111	124	138	138	166
70	40	48	56	65	73	81	89	97	105	113	129	145	161	161	194
80	46	55	65	74	83	92	101	111	120	129	147	166	184	184	221
90	52	62	73	83	93	104	114	124	135	145	166	187	207	207	249
100	58	69	81	92	104	115	127	138	150	161	184	207	230	230	276
110	63	76	89	101	114	127	139	152	165	177	203	228	253	253	
120	69	83	97	111	124	138	152	166	180	194	221	249	276	276	
130	75	90	105	120	135	150	165	180	195	210	240	270	300	300	
140	81	97	113	129	145	161	177	194	210	226	258	290			
150	86	104	121	138	156	173	190	207	225	242	276				
160	92	111	129	147	166	184	203	221	240	258	295				
170	98	118	137	157	176	196	215	235	255	274					
180	104	124	145	166	187	207	228	249	270	290					
190	109	131	153	175	197	219	241	263	285						
200	115	138	161	184	207	230	253	276	300						
210	121	145	169	194	218	242	266	290							
220	127	152	177	203	228	253	279								
230	132	159	185	212	238	265	291								
240	138	166	194	221	249	276									
250	144	173	202	230	259	288									
260	150	180	210	240	270	300									
270	156	187	218	249	280										
280	161	194	226	258	290										
290	167	200	234	267											
300	173	207	242	276											
320	184	221	258	295											
340	196	235	274												
360	207	249	290												
380	219	263													
400	230	276													
425	245	294													
450	259														
475	274														
500	288														
525															
550															
575															
600															

Gear Box...Low. Gear		RATE CHART LB. PER ACRE gb007, 730																		
Density Lb. Per Cu Ft.		50 Figures in body of chart = mm of door opening																		
Width.	25	30	35	40	45	50	55	60	65	70	80	90	100	120	130					
Rate																				
20														27	29	33	37	41	50	50
30														40	44	50	56	62	62	75
40														54	58	66	75	83	83	100
50	26	31	36	41	47	52	57	62	67	73	83	93	104	104	104	124	124	124	124	149
60	31	37	44	50	56	62	68	75	81	87	100	112	124	124	124	149	149	149	149	174
70	36	44	51	58	65	73	80	87	94	102	116	131	145	145	145	174	174	174	174	199
80	41	50	58	66	75	83	91	100	108	116	133	149	166	166	166	199	199	199	199	224
90	47	56	65	75	84	93	103	112	121	131	149	168	187	187	187	224	224	224	224	249
100	52	62	73	83	93	104	114	124	135	145	166	187	207	207	207	249	249	249	249	274
110	57	68	80	91	103	114	125	137	148	160	182	205	228	228	228	274	274	274	274	299
120	62	75	87	100	112	124	137	149	162	174	199	224	249	249	249	299	299	299	299	
130	67	81	94	108	121	135	148	162	175	189	216	243	270	270	270					
140	73	87	102	116	131	145	160	174	189	203	232	261	290	290	290					
150	78	93	109	124	140	156	171	187	202	218	249	280								
160	83	100	116	133	149	166	182	199	216	232	265	299								
170	88	106	123	141	159	176	194	212	229	247	282									
180	93	112	131	149	168	187	205	224	243	261	299									
190	98	118	138	158	177	197	217	236	256	276										
200	104	124	145	166	187	207	228	249	270	290										
210	109	131	152	174	196	218	240	261	283											
220	114	137	160	182	205	228	251	274	297											
230	119	143	167	191	215	238	262	286												
240	124	149	174	199	224	249	274	299												
250	130	156	181	207	233	259	285													
260	135	162	189	216	243	270	297													
270	140	168	196	224	252	280														
280	145	174	203	232	261	290														
290	150	180	210	241	271															
300	156	187	218	249	280															
320	166	199	232	265	299															
340	176	212	247	282																
360	187	224	261	299																
380	197	236	276																	
400	207	249	290																	
425	220	264																		
450	233	280																		
475	246	295																		
500	259																			
525	272																			
550	285																			
575	298																			
600																				

For Use with [TRANSPREAD](#) Density Meter ..gb007, 730 Standard Jockey. Accuracy of final settings operators responsibility based on use
 ... Other rates and rate calculator can be viewed at www.transpread.com/spreaders/trailers, also available in XL format for your own computer.

Gear Box...Low. Gear RATE CHART LB. PER ACR gb007, 730															Gear Box...Low. Gear RATE CHART LB. PER ACRE gb007, 730																					
Density Lb. Per Cu Ft. 55 Figures in body of chart = mm of door opening															Density Lb. Per Cu Ft. 60 Figures in body of chart = mm of door opening																					
Width.	25	30	35	40	45	50	55	60	65	70	80	90	100	120	130	Width.	25	30	35	40	45	50	55	60	65	70	80	90	100	120	130					
Rate																Rate																				
20											26	30	34	38	45	45	20															41				
30											30	34	38	45	68	68	30															62				
40											34	38	45	57	75	90	40															83				
50			26	30	34	38					38	45	57	75	113	113	50																104			
60	28	34	40	45	51	57					42	48	57	75	136	136	60	26	31	36													124			
70	33	40	46	53	59	66					46	53	62	80	158	158	70	30	36	42														145		
80	38	45	53	60	68	75					50	57	66	84	181	181	80	35	41	48															166	
90	42	51	59	68	76	85					54	62	70	88	204	204	90	39	47	54															187	
100	47	57	66	75	85	94	104	113	123	132	151	170	189	189	226	226	100	43	52	60																207
110	52	62	73	83	93	104	114	124	135	145	166	187	207	207	249	249	110	48	57	67																228
120	57	68	79	90	102	113	124	136	147	158	181	204	226	226	271	271	120	52	62	73																249
130	61	74	86	98	110	123	135	147	159	172	196	221	245	245	294	294	130	56	67	79																270
140	66	79	92	106	119	132	145	158	172	185	211	238	264	264			140	60	73	85																290
150	71	85	99	113	127	141	156	170	184	198	226	254	283	283			150	65	78	91																
160	75	90	106	121	136	151	166	181	196	211	241	271					160	69	83	97																
170	80	96	112	128	144	160	176	192	208	224	256	288					170	73	88	103																
180	85	102	119	136	153	170	187	204	221	238	271						180	78	93	109																
190	90	107	125	143	161	179	197	215	233	251	287						190	82	98	115																
200	94	113	132	151	170	189	207	226	245	264							200	86	104	121																
210	99	119	139	158	178	198	218	238	257	277							210	91	109	127																
220	104	124	145	166	187	207	228	249	270	290							220	95	114	133																
230	108	130	152	173	195	217	238	260	282								230	99	119	139																
240	113	136	158	181	204	226	249	271	294								240	104	124	145																
250	118	141	165	189	212	236	259	283									250	108	130	151																
260	123	147	172	196	221	245	270	294									260	112	135	157																
270	127	153	178	204	229	254	280										270	117	140	163																
280	132	158	185	211	238	264	290										280	121	145	169																
290	137	164	191	219	246	273											290	125	150	175																
300	141	170	198	226	254	283											300	130	156	181																
320	151	181	211	241	271												320	138	166	194																
340	160	192	224	256	288												340	147	176	206																
360	170	204	238	271													360	156	187	218																
380	179	215	251	287													380	164	197	230																
400	189	226	264														400	173	207	242																
425	200	240	280														425	184	220	257																
450	212	254	297														450	194	233	272																
475	224	269															475	205	246	287																
500	236	283															500	216	259																	
525	247	297															525	227	272																	
550	259																550	238	285																	
575	271																575	248	298																	
600	283																600	259																		

For Use with [TRANSPREAD](#) Density Meter ..gb007, 730 Standard Jockey. Accuracy of final settings operators responsibility based on use
 ... Other rates and rate calculator can be viewed at www.transpread.com/spreaders/trailers, also available in XL format for your own computer.

Gear Box...Low. Gear		RATE CHART LB. PER ACRE gb007, 730													
Density Lb. Per Cu Ft.		Figures in body of chart = mm of door opening													
Width.	25	30	35	40	45	50	55	60	65	70	80	90	100	120	130
Rate															
20											26	29	32	38	38
30											31	33	38	43	48
40											41	45	51	57	64
50				26	29	32	35	38	41	45	51	57	64	64	77
60		29	33	38	43	48	53	57	62	67	77	86	96	96	115
70	28	33	39	45	50	56	61	67	73	78	89	100	112	112	134
80	32	38	45	51	57	64	70	77	83	89	102	115	128	128	153
90	36	43	50	57	65	72	79	86	93	100	115	129	144	144	172
100	40	48	56	64	72	80	88	96	104	112	128	144	160	160	191
110	44	53	61	70	79	88	97	105	114	123	140	158	175	175	211
120	48	57	67	77	86	96	105	115	124	134	153	172	191	191	230
130	52	62	73	83	93	104	114	124	135	145	166	187	207	207	249
140	56	67	78	89	100	112	123	134	145	156	179	201	223	223	268
150	60	72	84	96	108	120	132	144	156	167	191	215	239	239	287
160	64	77	89	102	115	128	140	153	166	179	204	230	255	255	
170	68	81	95	108	122	136	149	163	176	190	217	244	271	271	
180	72	86	100	115	129	144	158	172	187	201	230	258	287	287	
190	76	91	106	121	136	152	167	182	197	212	242	273			
200	80	96	112	128	144	160	175	191	207	223	255	287			
210	84	100	117	134	151	167	184	201	218	234	268				
220	88	105	123	140	158	175	193	211	228	246	281				
230	92	110	128	147	165	183	202	220	238	257	293				
240	96	115	134	153	172	191	211	230	249	268					
250	100	120	140	160	179	199	219	239	259	279					
260	104	124	145	166	187	207	228	249	270	290					
270	108	129	151	172	194	215	237	258	280						
280	112	134	156	179	201	223	246	268	290						
290	116	139	162	185	208	231	254	278							
300	120	144	167	191	215	239	263	287							
320	128	153	179	204	230	255	281								
340	136	163	190	217	244	271	298								
360	144	172	201	230	258	287									
380	152	182	212	242	273										
400	160	191	223	255	287										
425	169	203	237	271											
450	179	215	251	287											
475	189	227	265												
500	199	239	279												
525	209	251	293												
550	219	263													
575	229	275													
600	239	287													

Gear Box...Low. Gear		RATE CHART LB. PER ACRE gb007, 730													
Density Lb. Per Cu Ft.		Figures in body of chart = mm of door opening													
Width.	25	30	35	40	45	50	55	60	65	70	80	90	100	120	130
Rate															
20															
30														27	30
40														36	36
50														44	53
60														53	71
70														62	89
80														71	107
90														80	124
100														89	148
110														98	178
120														107	196
130														116	213
140														124	231
150														133	249
160														142	267
170														151	284
180														160	296
190														169	
200														178	
210														187	
220														196	
230														204	
240														213	
250														222	
260														231	
270														240	
280														249	
290														258	
300														267	
320														276	
340														284	
360														293	
380														300	
400															
425															
450															
475															
500															
525															
550															
575															
600															

For Use with [TRANSPREAD](#) Density Meter ..gb007, 730 Standard Jockey. Accuracy of final settings operators responsibility based on use
 ... Other rates and rate calculator can be viewed at www.transpread.com/spreaders/trailers, also available in XL format for your own computer.

Gear Box...Low. Gear		RATE CHART LB. PER ACRE gb007, 730													
Density Lb. Per Cu Ft.		75 Figures in body of chart = mm of door opening													
Width.	25	30	35	40	45	50	55	60	65	70	80	90	100	120	130
Rate															
20														28	33
30									27	29	33	37	41	41	50
40									36	39	44	50	55	55	66
50						28	30	33	45	48	55	62	69	69	83
60			29			33	37	41	54	58	66	75	83	83	100
70		29	34			39	44	48	53	58	63	68	77	87	97
80	28	33	39			44	50	55	61	66	72	77	88	100	111
90	31	37	44			50	56	62	68	75	81	87	100	112	124
100	35	41	48			55	62	69	76	83	90	97	111	124	138
110	38	46	53			61	68	76	84	91	99	106	122	137	152
120	41	50	58			66	75	83	91	100	108	116	133	149	166
130	45	54	63			72	81	90	99	108	117	126	144	162	180
140	48	58	68			77	87	97	106	116	126	135	155	174	194
150	52	62	73			83	93	104	114	124	135	145	166	187	207
160	55	66	77			88	100	111	122	133	144	155	177	199	221
170	59	71	82			94	106	118	129	141	153	165	188	212	235
180	62	75	87			100	112	124	137	149	162	174	199	224	249
190	66	79	92			105	118	131	144	158	171	184	210	236	263
200	69	83	97			111	124	138	152	166	180	194	221	249	276
210	73	87	102			116	131	145	160	174	189	203	232	261	290
220	76	91	106			122	137	152	167	182	198	213	243	274	
230	79	95	111			127	143	159	175	191	207	223	254	286	
240	83	100	116			133	149	166	182	199	216	232	265	299	
250	86	104	121			138	156	173	190	207	225	242	276		
260	90	108	126			144	162	180	198	216	234	252	288		
270	93	112	131			149	168	187	205	224	243	261	299		
280	97	116	135			155	174	194	213	232	252	271			
290	100	120	140			160	180	200	220	241	261	281			
300	104	124	145			166	187	207	228	249	270	290			
320	111	133	155			177	199	221	243	265	288				
340	118	141	165			188	212	235	259	282					
360	124	149	174			199	224	249	274	299					
380	131	158	184			210	236	263	289						
400	138	166	194			221	249	276							
425	147	176	206			235	264	294							
450	156	187	218			249	280								
475	164	197	230			263	295								
500	173	207	242			276									
525	181	218	254			290									
550	190	228	266												
575	199	238	278												
600	207	249	290												

Gear Box...Low. Gear		RATE CHART LB. PER ACRE gb007, 730													
Density Lb. Per Cu Ft.		80 Figures in body of chart = mm of door opening													
Width.	25	30	35	40	45	50	55	60	65	70	80	90	100	120	130
Rate															
20															
30															
40														26	29
50														31	34
60														34	36
70														41	47
80	26	31												42	45
90	29	35												52	58
100	32	39												54	62
110	36	43												58	65
120	39	47												62	70
130	42	51												67	78
140	45	54												70	83
150	49	58												73	88
160	52	62												77	93
170	55	66												81	99
180	58	70												85	104
190	62	74												89	109
200	65	78												93	116
210	68	82												97	121
220	71	86												101	127
230	75	89												105	133
240	78	93												109	139
250	81	97												113	145
260	84	101												117	151
270	87	105												121	157
280	91	109												125	163
290	94	113												129	169
300	97	117												133	175
320	104	124												137	181
340	110	132												141	187
360	117	140												145	193
380	123	148												149	199
400	130	156												153	205
425	138	165												157	211
450	146	175												161	217
475	154	185												165	223
500	162	194												169	229
525	170	204												173	235
550	178	214												177	241
575	186	224												181	247
600	194	233												185	253

For Use with [TRANSPREAD](#) Density Meter ..gb007, 730 Standard Jockey. Accuracy of final settings operators responsibility based on use
 ... Other rates and rate calculator can be viewed at www.transpread.com/spreaders/trailers, also available in XL format for your own computer.

Gear Box...Low. Gear		RATE CHART LB. PER ACRE gb007, 730													
Density Lb. Per Cu Ft.		90 Figures in body of chart = mm of door opening													
Width.	25	30	35	40	45	50	55	60	65	70	80	90	100	120	130
Rate															
20														28	28
30											28	31	35	35	41
40											32	37	41	46	55
50					26	29	32	35	37	40	46	52	58	58	69
60				28	31	35	38	41	45	48	55	62	69	69	83
70			28	32	36	40	44	48	52	56	65	73	81	81	97
80		28	32	37	41	46	51	55	60	65	74	83	92	92	111
90	26	31	36	41	47	52	57	62	67	73	83	93	104	104	124
100	29	35	40	46	52	58	63	69	75	81	92	104	115	115	138
110	32	38	44	51	57	63	70	76	82	89	101	114	127	127	152
120	35	41	48	55	62	69	76	83	90	97	111	124	138	138	166
130	37	45	52	60	67	75	82	90	97	105	120	135	150	150	180
140	40	48	56	65	73	81	89	97	105	113	129	145	161	161	194
150	43	52	60	69	78	86	95	104	112	121	138	156	173	173	207
160	46	55	65	74	83	92	101	111	120	129	147	166	184	184	221
170	49	59	69	78	88	98	108	118	127	137	157	176	196	196	235
180	52	62	73	83	93	104	114	124	135	145	166	187	207	207	249
190	55	66	77	88	98	109	120	131	142	153	175	197	219	219	263
200	58	69	81	92	104	115	127	138	150	161	184	207	230	230	276
210	60	73	85	97	109	121	133	145	157	169	194	218	242	242	290
220	63	76	89	101	114	127	139	152	165	177	203	228	253	253	
230	66	79	93	106	119	132	146	159	172	185	212	238	265	265	
240	69	83	97	111	124	138	152	166	180	194	221	249	276	276	
250	72	86	101	115	130	144	158	173	187	202	230	259	288	288	
260	75	90	105	120	135	150	165	180	195	210	240	270	300	300	
270	78	93	109	124	140	156	171	187	202	218	249	280			
280	81	97	113	129	145	161	177	194	210	226	258	290			
290	84	100	117	134	150	167	184	200	217	234	267				
300	86	104	121	138	156	173	190	207	225	242	276				
320	92	111	129	147	166	184	203	221	240	258	295				
340	98	118	137	157	176	196	215	235	255	274					
360	104	124	145	166	187	207	228	249	270	290					
380	109	131	153	175	197	219	241	263	285						
400	115	138	161	184	207	230	253	276	300						
425	122	147	171	196	220	245	269	294							
450	130	156	181	207	233	259	285								
475	137	164	192	219	246	274									
500	144	173	202	230	259	288									
525	151	181	212	242	272										
550	158	190	222	253	285										
575	166	199	232	265	298										
600	173	207	242	276											

Gear Box...Low. Gear		RATE CHART LB. PER ACRE gb007, 730													
Density Lb. Per Cu Ft.		100 Figures in body of chart = mm of door opening													
Width.	25	30	35	40	45	50	55	60	65	70	80	90	100	120	130
Rate															
20															
30														28	31
40														33	37
50														34	41
60														34	44
70														34	47
80														34	51
90														34	58
100														34	65
110														34	73
120														34	83
130														34	93
140														34	104
150														34	115
160														34	127
170														34	140
180														34	154
190														34	169
200														34	185
210														34	202
220														34	220
230														34	239
240														34	259
250														34	280
260														34	302
270														34	325
280														34	350
290														34	377
300														34	406
320														34	437
340														34	470
360														34	505
380														34	542
400														34	581
425														34	622
450														34	665
475														34	710
500														34	757
525														34	806
550														34	857
575														34	910
600														34	965

For Use with **TRANSPREAD** Density Meter .. gb007, 730, Standard Jockey. Accuracy of final settings operators responsibility based on use ... Other rates and rate calculator can be viewed at www.transpread.com/spreaders/trailers, also available in XL format for your own computer.

Gear Box...Med. Gear		RATE CHART LB. PER ACRE gb007, 730													
Density Lb. Per Cu Ft.		45 Figures in body of chart = mm of door opening													
Width.	25	30	35	40	45	50	55	60	65	70	80	90	100	120	130
Rate															
200	47	56	66	75	84	94	103	112	122	131	150	168	187	225	225
225	53	63	74	84	95	105	116	126	137	147	168	190	211	211	253
250	59	70	82	94	105	117	129	140	152	164	187	211	234	234	281
275	64	77	90	103	116	129	142	154	167	180	206	232	257	257	
300	70	84	98	112	126	140	154	168	183	197	225	253	281	281	
325	76	91	106	122	137	152	167	183	198	213	243	274			
350	82	98	115	131	147	164	180	197	213	229	262	295			
375	88	105	123	140	158	176	193	211	228	246	281				
400	94	112	131	150	168	187	206	225	243	262	300				
425	99	119	139	159	179	199	219	239	259	278					
450	105	126	147	168	190	211	232	253	274	295					
475	111	133	156	178	200	222	245	267	289						
500	117	140	164	187	211	234	257	281							
525	123	147	172	197	221	246	270	295							
550	129	154	180	206	232	257	283								
575	135	161	188	215	242	269	296								
600	140	168	197	225	253	281									
625	146	176	205	234	263	293									
650	152	183	213	243	274										
675	158	190	221	253	284										
700	164	197	229	262	295										
750	176	211	246	281											
800	187	225	262	300											
850	199	239	278												
900	211	253	295												
950	222	267													
1000	234	281													
1050	246	295													
1100	257														
1150	269														
1200	281														
1250	293														
1300															
1350															
1400															
1450															
1500															
1550															
1600															
1650															
1700															
1800															

Gear Box...Med. Gear		RATE CHART LB. PER ACRE gb007, 730													
Density Lb. Per Cu Ft.		50 Figures in body of chart = mm of door opening													
Width.	25	30	35	40	45	50	55	60	65	70	80	90	100	120	130
Rate															
200	42	51	59	67	76	84	93	101	110	118	135	152	168	202	202
225	47	57	66	76	85	95	104	114	123	133	152	171	190	190	227
250	53	63	74	84	95	105	116	126	137	147	168	190	211	211	253
275	58	69	81	93	104	116	127	139	151	162	185	208	232	232	278
300	63	76	88	101	114	126	139	152	164	177	202	227	253	253	
325	68	82	96	110	123	137	151	164	178	192	219	246	274	274	
350	74	88	103	118	133	147	162	177	192	206	236	265	295	295	
375	79	95	111	126	142	158	174	190	205	221	253	284			
400	84	101	118	135	152	168	185	202	219	236	270				
425	90	107	125	143	161	179	197	215	233	251	286				
450	95	114	133	152	171	190	208	227	246	265					
475	100	120	140	160	180	200	220	240	260	280					
500	105	126	147	168	190	211	232	253	274	295					
525	111	133	155	177	199	221	243	265	287						
550	116	139	162	185	208	232	255	278							
575	121	145	170	194	218	242	266	291							
600	126	152	177	202	227	253	278								
625	132	158	184	211	237	263	290								
650	137	164	192	219	246	274									
675	142	171	199	227	256	284									
700	147	177	206	236	265	295									
750	158	190	221	253	284										
800	168	202	236	270											
850	179	215	251	286											
900	190	227	265												
950	200	240	280												
1000	211	253	295												
1050	221	265													
1100	232	278													
1150	242	291													
1200	253														
1250	263														
1300	274														
1350	284														
1400	295														
1450															
1500															
1550															
1600															
1650															
1700															
1800															

For Use with **TRANSPREAD** Density Meter .. gb007, 730, Standard Jockey. Accuracy of final settings operators responsibility based on use ... Other rates and rate calculator can be viewed at www.transpread.com/spreaders/trailers, also available in XL format for your own computer.

Gear Box...Med. Gear		RATE CHART LB. PER ACRE gb007, 730													
Density Lb. Per Cu Ft.		55 Figures in body of chart = mm of door opening													
Width.	25	30	35	40	45	50	55	60	65	70	80	90	100	120	130
Rate															
200	38	46	54	61	69	77	84	92	100	107	123	138	153	184	184
225	43	52	60	69	78	86	95	103	112	121	138	155	172	172	207
250	48	57	67	77	86	96	105	115	124	134	153	172	191	191	230
275	53	63	74	84	95	105	116	126	137	147	168	190	211	211	253
300	57	69	80	92	103	115	126	138	149	161	184	207	230	230	276
325	62	75	87	100	112	124	137	149	162	174	199	224	249	249	299
350	67	80	94	107	121	134	147	161	174	188	214	241	268	268	
375	72	86	101	115	129	144	158	172	187	201	230	258	287	287	
400	77	92	107	123	138	153	168	184	199	214	245	276			
425	81	98	114	130	146	163	179	195	212	228	260	293			
450	86	103	121	138	155	172	190	207	224	241	276				
475	91	109	127	146	164	182	200	218	236	255	291				
500	96	115	134	153	172	191	211	230	249	268					
525	101	121	141	161	181	201	221	241	261	281					
550	105	126	147	168	190	211	232	253	274	295					
575	110	132	154	176	198	220	242	264	286						
600	115	138	161	184	207	230	253	276	299						
625	120	144	168	191	215	239	263	287							
650	124	149	174	199	224	249	274	299							
675	129	155	181	207	233	258	284								
700	134	161	188	214	241	268	295								
750	144	172	201	230	258	287									
800	153	184	214	245	276										
850	163	195	228	260	293										
900	172	207	241	276											
950	182	218	255	291											
1000	191	230	268												
1050	201	241	281												
1100	211	253	295												
1150	220	264													
1200	230	276													
1250	239	287													
1300	249	299													
1350	258														
1400	268														
1450	278														
1500	287														
1550	297														
1600															
1650															
1700															
1800															

Gear Box...Med. Gear		RATE CHART LB. PER ACRE gb007, 730													
Density Lb. Per Cu Ft.		60 Figures in body of chart = mm of door opening													
Width.	25	30	35	40	45	50	55	60	65	70	80	90	100	120	130
Rate															
200	35	42	49	56	63	70	77	84	91	98	112	126	140	168	168
225	39	47	55	63	71	79	87	95	103	111	126	142	158	158	190
250	44	53	61	70	79	88	97	105	114	123	140	158	176	176	211
275	48	58	68	77	87	97	106	116	125	135	154	174	193	193	232
300	53	63	74	84	95	105	116	126	137	147	168	190	211	211	253
325	57	68	80	91	103	114	125	137	148	160	183	205	228	228	274
350	61	74	86	98	111	123	135	147	160	172	197	221	246	246	295
375	66	79	92	105	118	132	145	158	171	184	211	237	263	263	
400	70	84	98	112	126	140	154	168	183	197	225	253	281	281	
425	75	90	104	119	134	149	164	179	194	209	239	269	298	298	
450	79	95	111	126	142	158	174	190	205	221	253	284			
475	83	100	117	133	150	167	183	200	217	233	267				
500	88	105	123	140	158	176	193	211	228	246	281				
525	92	111	129	147	166	184	203	221	240	258	295				
550	97	116	135	154	174	193	212	232	251	270					
575	101	121	141	161	182	202	222	242	262	283					
600	105	126	147	168	190	211	232	253	274	295					
625	110	132	154	176	197	219	241	263	285						
650	114	137	160	183	205	228	251	274	297						
675	118	142	166	190	213	237	261	284							
700	123	147	172	197	221	246	270	295							
750	132	158	184	211	237	263	290								
800	140	168	197	225	253	281									
850	149	179	209	239	269	298									
900	158	190	221	253	284										
950	167	200	233	267											
1000	176	211	246	281											
1050	184	221	258	295											
1100	193	232	270												
1150	202	242	283												
1200	211	253	295												
1250	219	263													
1300	228	274													
1350	237	284													
1400	246	295													
1450	254														
1500	263														
1550	272														
1600	281														
1650	290														
1700	298														
1800															

For Use with **TRANSPREAD** Density Meter .. gb007, 730, Standard Jockey. Accuracy of final settings operators responsibility based on use ... Other rates and rate calculator can be viewed at www.transpread.com/spreaders/trailers, also available in XL format for your own computer.

Gear Box...Med. Gear		RATE CHART LB. PER ACRE gb007, 730													
Density Lb. Per Cu Ft. 65		Figures in body of chart = mm of door opening													
Width.	25	30	35	40	45	50	55	60	65	70	80	90	100	120	130
Rate 200	32	39	45	52	58	65	71	78	84	91	104	117	130	156	156
225	36	44	51	58	66	73	80	87	95	102	117	131	146	146	175
250	40	49	57	65	73	81	89	97	105	113	130	146	162	162	194
275	45	53	62	71	80	89	98	107	116	125	143	160	178	178	214
300	49	58	68	78	87	97	107	117	126	136	156	175	194	194	233
325	53	63	74	84	95	105	116	126	137	147	168	190	211	211	253
350	57	68	79	91	102	113	125	136	147	159	181	204	227	227	272
375	61	73	85	97	109	121	134	146	158	170	194	219	243	243	292
400	65	78	91	104	117	130	143	156	168	181	207	233	259	259	-
425	69	83	96	110	124	138	151	165	179	193	220	248	275	275	-
450	73	87	102	117	131	146	160	175	190	204	233	262	292	292	-
475	77	92	108	123	139	154	169	185	200	215	246	277	-	-	-
500	81	97	113	130	146	162	178	194	211	227	259	292	-	-	-
525	85	102	119	136	153	170	187	204	221	238	272	-	-	-	-
550	89	107	125	143	160	178	196	214	232	249	285	-	-	-	-
575	93	112	130	149	168	186	205	224	242	261	298	-	-	-	-
600	97	117	136	156	175	194	214	233	253	272	-	-	-	-	-
625	101	122	142	162	182	202	223	243	263	284	-	-	-	-	-
650	105	126	147	168	190	211	232	253	274	295	-	-	-	-	-
675	109	131	153	175	197	219	241	262	284	-	-	-	-	-	-
700	113	136	159	181	204	227	249	272	295	-	-	-	-	-	-
750	121	146	170	194	219	243	267	292	-	-	-	-	-	-	-
800	130	156	181	207	233	259	285	-	-	-	-	-	-	-	-
850	138	165	193	220	248	275	-	-	-	-	-	-	-	-	-
900	146	175	204	233	262	292	-	-	-	-	-	-	-	-	-
950	154	185	215	246	277	-	-	-	-	-	-	-	-	-	-
1000	162	194	227	259	292	-	-	-	-	-	-	-	-	-	-
1050	170	204	238	272	-	-	-	-	-	-	-	-	-	-	-
1100	178	214	249	285	-	-	-	-	-	-	-	-	-	-	-
1150	186	224	261	298	-	-	-	-	-	-	-	-	-	-	-
1200	194	233	272	-	-	-	-	-	-	-	-	-	-	-	-
1250	202	243	284	-	-	-	-	-	-	-	-	-	-	-	-
1300	211	253	295	-	-	-	-	-	-	-	-	-	-	-	-
1350	219	262	-	-	-	-	-	-	-	-	-	-	-	-	-
1400	227	272	-	-	-	-	-	-	-	-	-	-	-	-	-
1450	235	282	-	-	-	-	-	-	-	-	-	-	-	-	-
1500	243	292	-	-	-	-	-	-	-	-	-	-	-	-	-
1550	251	-	-	-	-	-	-	-	-	-	-	-	-	-	-
1600	259	-	-	-	-	-	-	-	-	-	-	-	-	-	-
1650	267	-	-	-	-	-	-	-	-	-	-	-	-	-	-
1700	275	-	-	-	-	-	-	-	-	-	-	-	-	-	-
1800	292	-	-	-	-	-	-	-	-	-	-	-	-	-	-

Gear Box...Med. Gear		RATE CHART LB. PER ACRE gb007, 730													
Density Lb. Per Cu Ft. 70		Figures in body of chart = mm of door opening													
Width.	25	30	35	40	45	50	55	60	65	70	80	90	100	120	130
Rate 200	30	36	42	48	54	60	66	72	78	84	96	108	120	144	144
225	34	41	47	54	61	68	74	81	88	95	108	122	135	135	162
250	38	45	53	60	68	75	83	90	98	105	120	135	150	150	181
275	41	50	58	66	74	83	91	99	108	116	132	149	165	165	199
300	45	54	63	72	81	90	99	108	117	126	144	162	181	181	217
325	49	59	68	78	88	98	108	117	127	137	156	176	196	196	235
350	53	63	74	84	95	105	116	126	137	147	168	190	211	211	253
375	56	68	79	90	102	113	124	135	147	158	181	203	226	226	271
400	60	72	84	96	108	120	132	144	156	168	193	217	241	241	289
425	64	77	90	102	115	128	141	153	166	179	205	230	256	256	-
450	68	81	95	108	122	135	149	162	176	190	217	244	271	271	-
475	71	86	100	114	129	143	157	171	186	200	229	257	286	286	-
500	75	90	105	120	135	150	165	181	196	211	241	271	-	-	-
525	79	95	111	126	142	158	174	190	205	221	253	284	-	-	-
550	83	99	116	132	149	165	182	199	215	232	265	298	-	-	-
575	86	104	121	138	156	173	190	208	225	242	277	-	-	-	-
600	90	108	126	144	162	181	199	217	235	253	289	-	-	-	-
625	94	113	132	150	169	188	207	226	244	263	-	-	-	-	-
650	98	117	137	156	176	196	215	235	254	274	-	-	-	-	-
675	102	122	142	162	183	203	223	244	264	284	-	-	-	-	-
700	105	126	147	168	190	211	232	253	274	295	-	-	-	-	-
750	113	135	158	181	203	226	248	271	293	-	-	-	-	-	-
800	120	144	168	193	217	241	265	289	-	-	-	-	-	-	-
850	128	153	179	205	230	256	281	-	-	-	-	-	-	-	-
900	135	162	190	217	244	271	298	-	-	-	-	-	-	-	-
950	143	171	200	229	257	286	-	-	-	-	-	-	-	-	-
1000	150	181	211	241	271	-	-	-	-	-	-	-	-	-	-
1050	158	190	221	253	284	-	-	-	-	-	-	-	-	-	-
1100	165	199	232	265	298	-	-	-	-	-	-	-	-	-	-
1150	173	208	242	277	-	-	-	-	-	-	-	-	-	-	-
1200	181	217	253	289	-	-	-	-	-	-	-	-	-	-	-
1250	188	226	263	-	-	-	-	-	-	-	-	-	-	-	-
1300	196	235	274	-	-	-	-	-	-	-	-	-	-	-	-
1350	203	244	284	-	-	-	-	-	-	-	-	-	-	-	-
1400	211	253	295	-	-	-	-	-	-	-	-	-	-	-	-
1450	218	262	-	-	-	-	-	-	-	-	-	-	-	-	-
1500	226	271	-	-	-	-	-	-	-	-	-	-	-	-	-
1550	233	280	-	-	-	-	-	-	-	-	-	-	-	-	-
1600	241	289	-	-	-	-	-	-	-	-	-	-	-	-	-
1650	248	298	-	-	-	-	-	-	-	-	-	-	-	-	-
1700	256	-	-	-	-	-	-	-	-	-	-	-	-	-	-
1800	271	-	-	-	-	-	-	-	-	-	-	-	-	-	-

For Use with **TRANSPREAD** Density Meter .. gb007, 730, Standard Jockey. Accuracy of final settings operators responsibility based on use
 ... Other rates and rate calculator can be viewed at www.transpread.com/spreaders/trailers, also available in XL format for your own computer.

Gear Box...Med. Gear		RATE CHART LB. PER ACRE gb007, 730													
Density Lb. Per Cu Ft.		75 Figures in body of chart = mm of door opening													
Width.	25	30	35	40	45	50	55	60	65	70	80	90	100	120	130
Rate															
200	28	34	39	45	51	56	62	67	73	79	90	101	112	135	135
225	32	38	44	51	57	63	69	76	82	88	101	114	126	126	152
250	35	42	49	56	63	70	77	84	91	98	112	126	140	140	168
275	39	46	54	62	69	77	85	93	100	108	124	139	154	154	185
300	42	51	59	67	76	84	93	101	110	118	135	152	168	168	202
325	46	55	64	73	82	91	100	110	119	128	146	164	183	183	219
350	49	59	69	79	88	98	108	118	128	138	157	177	197	197	236
375	53	63	74	84	95	105	116	126	137	147	168	190	211	211	253
400	56	67	79	90	101	112	124	135	146	157	180	202	225	225	270
425	60	72	84	95	107	119	131	143	155	167	191	215	239	239	286
450	63	76	88	101	114	126	139	152	164	177	202	227	253	253	
475	67	80	93	107	120	133	147	160	173	187	213	240	267	267	
500	70	84	98	112	126	140	154	168	183	197	225	253	281	281	
525	74	88	103	118	133	147	162	177	192	206	236	265	295	295	
550	77	93	108	124	139	154	170	185	201	216	247	278			
575	81	97	113	129	145	161	178	194	210	226	258	291			
600	84	101	118	135	152	168	185	202	219	236	270				
625	88	105	123	140	158	176	193	211	228	246	281				
650	91	110	128	146	164	183	201	219	237	256	292				
675	95	114	133	152	171	190	208	227	246	265					
700	98	118	138	157	177	197	216	236	256	275					
750	105	126	147	168	190	211	232	253	274	295					
800	112	135	157	180	202	225	247	270	292						
850	119	143	167	191	215	239	263	286							
900	126	152	177	202	227	253	278								
950	133	160	187	213	240	267	293								
1000	140	168	197	225	253	281									
1050	147	177	206	236	265	295									
1100	154	185	216	247	278										
1150	161	194	226	258	291										
1200	168	202	236	270											
1250	176	211	246	281											
1300	183	219	256	292											
1350	190	227	265												
1400	197	236	275												
1450	204	244	285												
1500	211	253	295												
1550	218	261													
1600	225	270													
1650	232	278													
1700	239	286													
1800	253														

Gear Box...Med. Gear		RATE CHART LB. PER ACRE gb007, 730													
Density Lb. Per Cu Ft.		80 Figures in body of chart = mm of door opening													
Width.	25	30	35	40	45	50	55	60	65	70	80	90	100	120	130
Rate															
200	26	32	37	42	47	53	58	63	68	74	84	95	105	126	126
225	30	36	41	47	53	59	65	71	77	83	95	107	118	118	142
250	33	39	46	53	59	66	72	79	86	92	105	118	132	132	158
275	36	43	51	58	65	72	80	87	94	101	116	130	145	145	174
300	39	47	55	63	71	79	87	95	103	111	126	142	158	158	190
325	43	51	60	68	77	86	94	103	111	120	137	154	171	171	205
350	46	55	64	74	83	92	101	111	120	129	147	166	184	184	221
375	49	59	69	79	89	99	109	118	128	138	158	178	197	197	237
400	53	63	74	84	95	105	116	126	137	147	168	190	211	211	253
425	56	67	78	90	101	112	123	134	145	157	179	201	224	224	269
450	59	71	83	95	107	118	130	142	154	166	190	213	237	237	284
475	63	75	88	100	113	125	138	150	163	175	200	225	250	250	
500	66	79	92	105	118	132	145	158	171	184	211	237	263	263	
525	69	83	97	111	124	138	152	166	180	193	221	249	276	276	
550	72	87	101	116	130	145	159	174	188	203	232	261	290	290	
575	76	91	106	121	136	151	167	182	197	212	242	272			
600	79	95	111	126	142	158	174	190	205	221	253	284			
625	82	99	115	132	148	165	181	197	214	230	263	296			
650	86	103	120	137	154	171	188	205	222	240	274				
675	89	107	124	142	160	178	195	213	231	249	284				
700	92	111	129	147	166	184	203	221	240	258	295				
750	99	118	138	158	178	197	217	237	257	276					
800	105	126	147	168	190	211	232	253	274	295					
850	112	134	157	179	201	224	246	269	291						
900	118	142	166	190	213	237	261	284							
950	125	150	175	200	225	250	275								
1000	132	158	184	211	237	263	290								
1050	138	166	193	221	249	276									
1100	145	174	203	232	261	290									
1150	151	182	212	242	272										
1200	158	190	221	253	284										
1250	165	197	230	263	296										
1300	171	205	240	274											
1350	178	213	249	284											
1400	184	221	258	295											
1450	191	229	267												
1500	197	237	276												
1550	204	245	286												
1600	211	253	295												
1650	217	261													
1700	224	269													
1800	237	284													

For Use with **TRANSPREAD** Density Meter .. gb007, 730, Standard Jockey. Accuracy of final settings operators responsibility based on use
 ... Other rates and rate calculator can be viewed at www.transpread.com/spreaders/trailers, also available in XL format for your own computer.

Gear Box...Med. Gear		RATE CHART LB. PER ACRE gb007, 730													
Density Lb. Per Cu Ft.		90													
		Figures in body of chart = mm of door opening													
Width.	25	30	35	40	45	50	55	60	65	70	80	90	100	120	130
Rate															
200		28	33	37	42	47	51	56	61	66	75	84	94	112	112
225	26	32	37	42	47	53	58	63	68	74	84	95	105	105	126
250	29	35	41	47	53	59	64	70	76	82	94	105	117	117	140
275	32	39	45	51	58	64	71	77	84	90	103	116	129	129	154
300	35	42	49	56	63	70	77	84	91	98	112	126	140	140	168
325	38	46	53	61	68	76	84	91	99	106	122	137	152	152	183
350	41	49	57	66	74	82	90	98	106	115	131	147	164	164	197
375	44	53	61	70	79	88	97	105	114	123	140	158	176	176	211
400	47	56	66	75	84	94	103	112	122	131	150	168	187	187	225
425	50	60	70	80	90	99	109	119	129	139	159	179	199	199	239
450	53	63	74	84	95	105	116	126	137	147	168	190	211	211	253
475	56	67	78	89	100	111	122	133	144	156	178	200	222	222	267
500	59	70	82	94	105	117	129	140	152	164	187	211	234	234	281
525	61	74	86	98	111	123	135	147	160	172	197	221	246	246	295
550	64	77	90	103	116	129	142	154	167	180	206	232	257	257	
575	67	81	94	108	121	135	148	161	175	188	215	242	269	269	
600	70	84	98	112	126	140	154	168	183	197	225	253	281	281	
625	73	88	102	117	132	146	161	176	190	205	234	263	293	293	
650	76	91	106	122	137	152	167	183	198	213	243	274			
675	79	95	111	126	142	158	174	190	205	221	253	284			
700	82	98	115	131	147	164	180	197	213	229	262	295			
750	88	105	123	140	158	176	193	211	228	246	281				
800	94	112	131	150	168	187	206	225	243	262	300				
850	99	119	139	159	179	199	219	239	259	278					
900	105	126	147	168	190	211	232	253	274	295					
950	111	133	156	178	200	222	245	267	289						
1000	117	140	164	187	211	234	257	281							
1050	123	147	172	197	221	246	270	295							
1100	129	154	180	206	232	257	283								
1150	135	161	188	215	242	269	296								
1200	140	168	197	225	253	281									
1250	146	176	205	234	263	293									
1300	152	183	213	243	274										
1350	158	190	221	253	284										
1400	164	197	229	262	295										
1450	170	204	238	271											
1500	176	211	246	281											
1550	181	218	254	290											
1600	187	225	262	300											
1650	193	232	270												
1700	199	239	278												
1800	211	253	295												

Gear Box...Med. Gear		RATE CHART LB. PER ACRE gb007, 730													
Density Lb. Per Cu Ft.		100													
		Figures in body of chart = mm of door opening													
Width.	25	30	35	40	45	50	55	60	65	70	80	90	100	120	130
Rate															
200		25	29	34	38	42	46	51	55	59	67	76	84	101	101
225		28	33	38	43	47	52	57	62	66	76	85	95	95	114
250	26	32	37	42	47	53	58	63	68	74	84	95	105	105	126
275	29	35	41	46	52	58	64	69	75	81	93	104	116	116	139
300	32	38	44	51	57	63	69	76	82	88	101	114	126	126	152
325	34	41	48	55	62	68	75	82	89	96	110	123	137	137	164
350	37	44	52	59	66	74	81	88	96	103	118	133	147	147	177
375	39	47	55	63	71	79	87	95	103	111	126	142	158	158	190
400	42	51	59	67	76	84	93	101	110	118	135	152	168	168	202
425	45	54	63	72	81	90	98	107	116	125	143	161	179	179	215
450	47	57	66	76	85	95	104	114	123	133	152	171	190	190	227
475	50	60	70	80	90	100	110	120	130	140	160	180	200	200	240
500	53	63	74	84	95	105	116	126	137	147	168	190	211	211	253
525	55	66	77	88	100	111	122	133	144	155	177	199	221	221	265
550	58	69	81	93	104	116	127	139	151	162	185	208	232	232	278
575	61	73	85	97	109	121	133	145	157	170	194	218	242	242	291
600	63	76	88	101	114	126	139	152	164	177	202	227	253	253	
625	66	79	92	105	118	132	145	158	171	184	211	237	263	263	
650	68	82	96	110	123	137	151	164	178	192	219	246	274	274	
675	71	85	100	114	128	142	156	171	185	199	227	256	284	284	
700	74	88	103	118	133	147	162	177	192	206	236	265	295	295	
750	79	95	111	126	142	158	174	190	205	221	253	284			
800	84	101	118	135	152	168	185	202	219	236	270				
850	90	107	125	143	161	179	197	215	233	251	286				
900	95	114	133	152	171	190	208	227	246	265					
950	100	120	140	160	180	200	220	240	260	280					
1000	105	126	147	168	190	211	232	253	274	295					
1050	111	133	155	177	199	221	243	265	287						
1100	116	139	162	185	208	232	255	278							
1150	121	145	170	194	218	242	266	291							
1200	126	152	177	202	227	253	278								
1250	132	158	184	211	237	263	290								
1300	137	164	192	219	246	274									
1350	142	171	199	227	256	284									
1400	147	177	206	236	265	295									
1450	153	183	214	244	275										
1500	158	190	221	253	284										
1550	163	196	229	261	294										
1600	168	202	236	270											
1650	174	208	243	278											
1700	179	215	251	286											
1800	190	227	265												

For Use with **TRANSPREAD** Density Meter .. gb007 730 Standard Jockey. Accuracy of final settings operators responsibility based on use
 ... Other rates and rate calculator can be viewed at www.transpread.com/spreaders/trailers, also available in XL format for your own computer.

Gear Box...High. Gear		RATE CHART LB. PER ACRE												gb007, 730	
Density Lb. Per Cu Ft.		45												Figures in body of chart = mm of door opening	
Width.	25	30	35	40	45	50	55	60	65	70	80	90	100	120	130
Rate															
500	33	39	46	52	59	66	72	79	85	92	105	118	131	157	170
525	34	41	48	55	62	69	76	83	89	96	110	124	138	165	179
550	36	43	50	58	65	72	79	87	94	101	115	130	144	173	187
575	38	45	53	60	68	75	83	90	98	106	121	136	151	181	196
600	39	47	55	63	71	79	87	94	102	110	126	142	157	189	204
625	41	49	57	66	74	82	90	98	107	115	131	147	164	197	213
650	43	51	60	68	77	85	94	102	111	119	136	153	170	204	222
675	44	53	62	71	80	88	97	106	115	124	142	159	177	212	230
700	46	55	64	73	83	92	101	110	119	128	147	165	184	220	239
750	49	59	69	79	88	98	108	118	128	138	157	177	197	236	256
800	52	63	73	84	94	105	115	126	136	147	168	189	210	252	273
850	56	67	78	89	100	111	123	134	145	156	178	201	223	267	290
900	59	71	83	94	106	118	130	142	153	165	189	212	236	283	307
950	62	75	87	100	112	125	137	149	162	174	199	224	249	299	
1000	66	79	92	105	118	131	144	157	170	184	210	236	262	315	
1050	69	83	96	110	124	138	151	165	179	193	220	248	275		
1100	72	87	101	115	130	144	159	173	187	202	231	260	288		
1150	75	90	106	121	136	151	166	181	196	211	241	271	301		
1200	79	94	110	126	142	157	173	189	204	220	252	283	315		
1250	82	98	115	131	147	164	180	197	213	229	262	295			
1300	85	102	119	136	153	170	187	204	222	239	273	307			
1350	88	106	124	142	159	177	195	212	230	248	283	319			
1400	92	110	128	147	165	184	202	220	239	257	294				
1450	95	114	133	152	171	190	209	228	247	266	304				
1500	98	118	138	157	177	197	216	236	256	275	315				
1550	102	122	142	163	183	203	223	244	264	284					
1600	105	126	147	168	189	210	231	252	273	294					
1650	108	130	151	173	195	216	238	260	281	303					
1700	111	134	156	178	201	223	245	267	290	312					
1800	118	142	165	189	212	236	260	283	307						
1900	125	149	174	199	224	249	274	299							
2000	131	157	184	210	236	262	288	315							
2500	164	197	229	262	295										
3000	197	236	275	315											
3500	229	275													
4000	262	315													
5000															
6000															
7000															
8000															
9000															
10000															

Gear Box...High. Gear		RATE CHART LB. PER ACRE												gb007, 730	
Density Lb. Per Cu Ft.		50												Figures in body of chart = mm of door opening	
Width.	25	30	35	40	45	50	55	60	65	70	80	90	100	120	130
Rate															
500	29	35	41	47	53	59	65	71	77	83	94	106	118	142	153
525	31	37	43	50	56	62	68	74	81	87	99	111	124	149	161
550	32	39	45	52	58	65	71	78	84	91	104	117	130	156	169
575	34	41	47	54	61	68	75	81	88	95	109	122	136	163	176
600	35	42	50	57	64	71	78	85	92	99	113	127	142	170	184
625	37	44	52	59	66	74	81	88	96	103	118	133	147	177	192
650	38	46	54	61	69	77	84	92	100	107	123	138	153	184	199
675	40	48	56	64	72	80	88	96	104	111	127	143	159	191	207
700	41	50	58	66	74	83	91	99	107	116	132	149	165	198	215
750	44	53	62	71	80	88	97	106	115	124	142	159	177	212	230
800	47	57	66	76	85	94	104	113	123	132	151	170	189	227	245
850	50	60	70	80	90	100	110	120	130	140	160	181	201	241	261
900	53	64	74	85	96	106	117	127	138	149	170	191	212	255	276
950	56	67	78	90	101	112	123	134	146	157	179	202	224	269	291
1000	59	71	83	94	106	118	130	142	153	165	189	212	236	283	307
1050	62	74	87	99	111	124	136	149	161	173	198	223	248	297	
1100	65	78	91	104	117	130	143	156	169	182	208	234	260	311	
1150	68	81	95	109	122	136	149	163	176	190	217	244	271		
1200	71	85	99	113	127	142	156	170	184	198	227	255	283		
1250	74	88	103	118	133	147	162	177	192	206	236	265	295		
1300	77	92	107	123	138	153	169	184	199	215	245	276	307		
1350	80	96	111	127	143	159	175	191	207	223	255	287	319		
1400	83	99	116	132	149	165	182	198	215	231	264	297			
1450	86	103	120	137	154	171	188	205	222	239	274	308			
1500	88	106	124	142	159	177	195	212	230	248	283	319			
1550	91	110	128	146	165	183	201	219	238	256	293				
1600	94	113	132	151	170	189	208	227	245	264	302				
1650	97	117	136	156	175	195	214	234	253	273	311				
1700	100	120	140	160	181	201	221	241	261	281					
1800	106	127	149	170	191	212	234	255	276	297					
1900	112	134	157	179	202	224	247	269	291	314					
2000	118	142	165	189	212	236	260	283	307						
2500	147	177	206	236	265	295									
3000	177	212	248	283	319										
3500	206	248	289												
4000	236	283													
5000	295														
6000															
7000															
8000															
9000															
10000															

For Use with **TRANSPREAD** Density Meter .. gb007 730 Standard Jockey. Accuracy of final settings operators responsibility based on use
 ... Other rates and rate calculator can be viewed at www.transpread.com/spreaders/trailers, also available in XL format for your own computer.

Gear Box...High. Gear		RATE CHART LB. PER ACRE												gb007, 730	
Density Lb. Per Cu Ft.		55												Figures in body of chart = mm of door opening	
Width.	25	30	35	40	45	50	55	60	65	70	80	90	100	120	130
Rate															
500	27	32	38	43	48	54	59	64	70	75	86	97	107	129	139
525	28	34	39	45	51	56	62	68	73	79	90	101	113	135	146
550	29	35	41	47	53	59	65	71	77	83	94	106	118	142	153
575	31	37	43	49	56	62	68	74	80	86	99	111	123	148	160
600	32	39	45	51	58	64	71	77	84	90	103	116	129	154	167
625	34	40	47	54	60	67	74	80	87	94	107	121	134	161	174
650	35	42	49	56	63	70	77	84	91	98	112	125	139	167	181
675	36	43	51	58	65	72	80	87	94	101	116	130	145	174	188
700	38	45	53	60	68	75	83	90	98	105	120	135	150	180	195
750	40	48	56	64	72	80	88	97	105	113	129	145	161	193	209
800	43	51	60	69	77	86	94	103	112	120	137	154	172	206	223
850	46	55	64	73	82	91	100	109	119	128	146	164	182	219	237
900	48	58	68	77	87	97	106	116	125	135	154	174	193	232	251
950	51	61	71	82	92	102	112	122	132	143	163	183	204	245	265
1000	54	64	75	86	97	107	118	129	139	150	172	193	215	257	279
1050	56	68	79	90	101	113	124	135	146	158	180	203	225	270	293
1100	59	71	83	94	106	118	130	142	153	165	189	212	236	283	307
1150	62	74	86	99	111	123	136	148	160	173	197	222	247	296	
1200	64	77	90	103	116	129	142	154	167	180	206	232	257	309	
1250	67	80	94	107	121	134	147	161	174	188	215	241	268		
1300	70	84	98	112	125	139	153	167	181	195	223	251	279		
1350	72	87	101	116	130	145	159	174	188	203	232	261	290		
1400	75	90	105	120	135	150	165	180	195	210	240	270	300		
1450	78	93	109	124	140	156	171	187	202	218	249	280	311		
1500	80	97	113	129	145	161	177	193	209	225	257	290			
1550	83	100	116	133	150	166	183	199	216	233	266	299			
1600	86	103	120	137	154	172	189	206	223	240	275	309			
1650	88	106	124	142	159	177	195	212	230	248	283	319			
1700	91	109	128	146	164	182	201	219	237	255	292				
1800	97	116	135	154	174	193	212	232	251	270	309				
1900	102	122	143	163	183	204	224	245	265	285					
2000	107	129	150	172	193	215	236	257	279	300					
2500	134	161	188	215	241	268	295								
3000	161	193	225	257	290										
3500	188	225	263	300											
4000	215	257	300												
5000	268														
6000															
7000															
8000															
9000															
10000															

Gear Box...High. Gear		RATE CHART LB. PER ACRE												gb007, 730	
Density Lb. Per Cu Ft.		60												Figures in body of chart = mm of door opening	
Width.	25	30	35	40	45	50	55	60	65	70	80	90	100	120	130
Rate															
500	29	34	39	44	49	54	59	64	69	79	88	98	108	118	128
525	26	31	36	41	46	52	57	62	67	72	83	93	103	113	124
550	27	32	38	43	49	54	59	65	70	76	87	97	108	118	130
575	28	34	40	45	51	57	62	68	73	79	90	102	113	123	136
600	29	35	41	47	53	59	65	71	77	83	94	106	118	128	142
625	31	37	43	49	55	61	68	74	80	86	98	111	123	133	147
650	32	38	45	51	58	64	70	77	83	89	102	115	128	138	153
675	33	40	46	53	60	66	73	80	86	93	106	119	133	143	159
700	34	41	48	55	62	69	76	83	89	96	110	124	138	148	165
750	37	44	52	59	66	74	81	88	96	103	118	133	147	157	177
800	39	47	55	63	71	79	87	94	102	110	126	142	157	167	189
850	42	50	58	67	75	84	92	100	109	117	134	150	167	177	201
900	44	53	62	71	80	88	97	106	115	124	142	159	177	187	212
950	47	56	65	75	84	93	103	112	121	131	149	168	187	197	224
1000	49	59	69	79	88	98	108	118	128	138	157	177	197	207	236
1050	52	62	72	83	93	103	114	124	134	145	165	186	206	216	248
1100	54	65	76	87	97	108	119	130	141	151	173	195	216	226	260
1150	57	68	79	90	102	113	124	136	147	158	181	204	226	236	271
1200	59	71	83	94	106	118	130	142	153	165	189	212	236	246	283
1250	61	74	86	98	111	123	135	147	160	172	197	221	246	256	295
1300	64	77	89	102	115	128	141	153	166	179	204	230	256	266	307
1350	66	80	93	106	119	133	146	159	173	186	212	239	265	275	319
1400	69	83	96	110	124	138	151	165	179	193	220	248	275		
1450	71	86	100	114	128	143	157	171	185	200	228	257	285		
1500	74	88	103	118	133	147	162	177	192	206	236	265	295		
1550	76	91	107	122	137	152	168	183	198	213	244	274	305		
1600	79	94	110	126	142	157	173	189	204	220	252	283	315		
1650	81	97	114	130	146	162	178	195	211	227	260	292			
1700	84	100	117	134	150	167	184	201	217	234	267	301			
1800	88	106	124	142	159	177	195	212	230	248	283	319			
1900	93	112	131	149	168	187	205	224	243	262	299				
2000	98	118	138	157	177	197	216	236	256	275	315				
2500	123	147	172	197	221	246	270	295	320						
3000	147	177	206	236	265	295									
3500	172	206	241	275	310										
4000	197	236	275	315											
5000	246	295													
6000	295														
7000															
8000															
9000															
10000															

For Use with [TRANSPREAD](#) Density Meter .. gb007 730 Standard Jockey. Accuracy of final settings operators responsibility based on use
 ... Other rates and rate calculator can be viewed at www.transpread.com/spreaders/trailers, also available in XL format for your own computer.

Gear Box...High. Gear		RATE CHART LB. PER ACRE												gb007, 730	
Density Lb. Per Cu Ft.		75												Figures in body of chart = mm of door opening	
Width.	25	30	35	40	45	50	55	60	65	70	80	90	100	120	130
Rate															
500			28	31	35	39	43	47	51	55	63	71	79	94	102
525			29	33	37	41	45	50	54	58	66	74	83	99	107
550		26	30	35	39	43	48	52	56	61	69	78	87	104	112
575		27	32	36	41	45	50	54	59	63	72	81	90	109	118
600		28	33	38	42	47	52	57	61	66	76	85	94	113	123
625		29	34	39	44	49	54	59	64	69	79	88	98	118	128
650	26	31	36	41	46	51	56	61	66	72	82	92	102	123	133
675	27	32	37	42	48	53	58	64	69	74	85	96	106	127	138
700	28	33	39	44	50	55	61	66	72	77	88	99	110	132	143
750	29	35	41	47	53	59	65	71	77	83	94	106	118	142	153
800	31	38	44	50	57	63	69	76	82	88	101	113	126	151	164
850	33	40	47	53	60	67	74	80	87	94	107	120	134	160	174
900	35	42	50	57	64	71	78	85	92	99	113	127	142	170	184
950	37	45	52	60	67	75	82	90	97	105	120	134	149	179	194
1000	39	47	55	63	71	79	87	94	102	110	126	142	157	189	204
1050	41	50	58	66	74	83	91	99	107	116	132	149	165	198	215
1100	43	52	61	69	78	87	95	104	112	121	138	156	173	208	225
1150	45	54	63	72	81	90	99	109	118	127	145	163	181	217	235
1200	47	57	66	76	85	94	104	113	123	132	151	170	189	227	245
1250	49	59	69	79	88	98	108	118	128	138	157	177	197	236	256
1300	51	61	72	82	92	102	112	123	133	143	164	184	204	245	266
1350	53	64	74	85	96	106	117	127	138	149	170	191	212	255	276
1400	55	66	77	88	99	110	121	132	143	154	176	198	220	264	286
1450	57	68	80	91	103	114	125	137	148	160	182	205	228	274	297
1500	59	71	83	94	106	118	130	142	153	165	189	212	236	283	307
1550	61	73	85	98	110	122	134	146	158	171	195	219	244	293	317
1600	63	76	88	101	113	126	138	151	164	176	201	227	252	302	
1650	65	78	91	104	117	130	143	156	169	182	208	234	260	311	
1700	67	80	94	107	120	134	147	160	174	187	214	241	267		
1800	71	85	99	113	127	142	156	170	184	198	227	255	283		
1900	75	90	105	120	134	149	164	179	194	209	239	269	299		
2000	79	94	110	126	142	157	173	189	204	220	252	283	315		
2500	98	118	138	157	177	197	216	236	256	275	315				
3000	118	142	165	189	212	236	260	283	307						
3500	138	165	193	220	248	275	303								
4000	157	189	220	252	283	315									
5000	197	236	275	315											
6000	236	283													
7000	275														
8000	315														
9000															
10000															

Gear Box...High. Gear		RATE CHART LB. PER ACRE												gb007, 730	
Density Lb. Per Cu Ft.		80												Figures in body of chart = mm of door opening	
Width.	25	30	35	40	45	50	55	60	65	70	80	90	100	120	130
Rate															
500			26	29	33	37	41	44	48	52	59	66	74	88	96
525			27	31	35	39	43	46	50	54	62	70	77	93	101
550			28	32	36	41	45	49	53	57	65	73	81	97	105
575		25	30	34	38	42	47	51	55	59	68	76	85	102	110
600		27	31	35	40	44	49	53	58	62	71	80	88	106	115
625		28	32	37	41	46	51	55	60	65	74	83	92	111	120
650		29	34	38	43	48	53	58	62	67	77	86	96	115	125
675		30	35	40	45	50	55	60	65	70	80	90	100	119	129
700	26	31	36	41	46	52	57	62	67	72	83	93	103	124	134
750	28	33	39	44	50	55	61	66	72	77	88	100	111	133	144
800	29	35	41	47	53	59	65	71	77	83	94	106	118	142	153
850	31	38	44	50	56	63	69	75	81	88	100	113	125	150	163
900	33	40	46	53	60	66	73	80	86	93	106	119	133	159	173
950	35	42	49	56	63	70	77	84	91	98	112	126	140	168	182
1000	37	44	52	59	66	74	81	88	96	103	118	133	147	177	192
1050	39	46	54	62	70	77	85	93	101	108	124	139	155	186	201
1100	41	49	57	65	73	81	89	97	105	114	130	146	162	195	211
1150	42	51	59	68	76	85	93	102	110	119	136	153	170	204	220
1200	44	53	62	71	80	88	97	106	115	124	142	159	177	212	230
1250	46	55	65	74	83	92	101	111	120	129	147	166	184	221	240
1300	48	58	67	77	86	96	105	115	125	134	153	173	192	230	249
1350	50	60	70	80	90	100	109	119	129	139	159	179	199	239	259
1400	52	62	72	83	93	103	114	124	134	145	165	186	206	248	268
1450	53	64	75	86	96	107	118	128	139	150	171	192	214	257	278
1500	55	66	77	88	100	111	122	133	144	155	177	199	221	265	288
1550	57	69	80	91	103	114	126	137	149	160	183	206	229	274	297
1600	59	71	83	94	106	118	130	142	153	165	189	212	236	283	307
1650	61	73	85	97	109	122	134	146	158	170	195	219	243	292	316
1700	63	75	88	100	113	125	138	150	163	175	201	226	251	301	
1800	66	80	93	106	119	133	146	159	173	186	212	239	265	319	
1900	70	84	98	112	126	140	154	168	182	196	224	252	280		
2000	74	88	103	118	133	147	162	177	192	206	236	265	295		
2500	92	111	129	147	166	184	203	221	240	258	295				
3000	111	133	155	177	199	221	243	265	288	310					
3500	129	155	181	206	232	258	284	310							
4000	147	177	206	236	265	295									
5000	184	221	258	295											
6000	221	265	310												
7000	258	310													
8000	295														
9000															
10000															

